


KV-D3421D

RM-684/SS-XT291

SERVICE MANUAL

AEP Model

Chassis No. SCC-C73B-A



DE-1 CHASSIS

Note: The service manual for RM-684 and SS-XT291 have been issued separately.


MODELS OF THE SAME SERIES

KV-D3421D	
KV-D3411D	

SPECIFICATIONS

Television system	B/G/H, I, L
Colour system	PAL, SECAM, NTSC4.43, NTSC3.58
Channel coverage	See "Receivable Channels and Channel Displays"
Picture tube	Trinitron tube Approx. 86 cm (34 inches) Approx. 80 cm (picture measured diagonally) 110 degree deflection
Inputs	Ⓖ-1 21-pin connector: CENELEC Standard Ⓖ-2 21-pin connector: RGB input unconnected 4-pin S video input connector Audio input jacks: phono jack
Outputs	External speaker terminals: 2-pin DIN Audio output jacks: phono jack — Output level dependent upon TV settings
Sound output	40 W + 40 W (music power)
Power consumption	146 Wh
Dimensions	Approx. 777 × 647 × 582 mm (w/h/d)
Weight	Approx. 73 kg
Supplied accessories	RM-684 Remote Commander (1) IEC designation R6 batteries (2)

Design and specifications are subject to change without notice.



TRINITRON® COLOR TV

SONY®

TABLE OF CONTENTS

Section	Title	Page	Section	Title	Page
1. GENERAL			4. CIRCUIT ADJUSTMENTS		
1-1.	Location and Function of Controls	3	4-1.	A Board Adjustment	15
1-2.	Preparation for Use	4	4-2.	B Board Adjustments	15
1-3.	To Preset Channels	5	4-3.	D Board Adjustment	16
1-4.	Watching TV Programmes	6	4-4.	V Board Adjustments	17
1-5.	Connecting other Equipment	7			
1-6.	Viewing Teletext	7	5. DIAGRAMS		
1-7.	Receivable Channels and Channel Displays	8	5-1.	Block Diagrams (1)	19
1-8.	Precautions	9	5-2.	Block Diagrams (2)	23
2. DISASSEMBLY			5-3.	Circuit Boards Location	27
2-1.	H1 Block Assy Removal	10	5-4.	Schematic Diagrams and Printed Wiring Boards — Conductor Side —	27
2-2.	A Board Removal	10	5-5.	Semiconductors	54
2-3.	Picture Tube Removal	11			
2-4.	Removal of Anode CAP	11	6. EXPLODED VIEWS		
3. SET-UP ADJUSTMENTS			6-1.	Chassis	55
3-1.	Beam Landing	12	6-2.	Picture Tube	56
3-2.	Convergence	13			
3-3.	White Balance	14	7. ELECTRICAL PARTS LIST		57

WARNING !!

AN ISOLATION TRANSFORMER SHOULD BE USED DURING ANY SERVICE TO AVOID POSSIBLE SHOCK HAZARD, BECAUSE OF LIVE CHASSIS. THE CHASSIS OF THIS RECEIVER IS DIRECTLY CONNECTED TO THE AC POWER LINE.


SAFETY-RELATED COMPONENT WARNING !!

COMPONENTS IDENTIFIED BY SHADING AND MARK  ON THE SCHEMATIC DIAGRAMS, EXPLODED VIEWS AND IN THE PARTS LIST ARE CRITICAL TO SAFE OPERATION. REPLACE THESE COMPONENTS WITH SONY PARTS WHOSE PART NUMBERS APPEAR AS SHOWN IN THIS MANUAL OR IN SUPPLEMENTS PUBLISHED BY SONY.

SECTION 1 GENERAL

1-1. LOCATION AND FUNCTION OF CONTROLS

Front



1 On-screen display

Indicates programme numbers, channel numbers, station labels, and input modes; $\odot$ -1, $\odot$ -2 and $\odot$ -.

Press $\odot$ on the Remote Commander to display them on the screen.

2 Bar display

Indicates the picture and sound adjustment items and their levels when they are adjusted.

3 Stereo A/B Indicator

Both indicators light up when a stereo programme is received.

4 Noise reduction indicator

5 Standby indicator


6 Remote control detector

Point the Remote Commander towards this detector.

7 POWER switch

To cut off the mains electricity supply, press this switch. Ensure correct operation by pressing this switch fully.

Rear



8 PROGR +/- buttons

Use to scan the available programmes, and to return to the TV mode from the standby mode when the Remote Commander is not available.

9 VOLUME +/- buttons

10 Colour system button

Press to select the colour system.

AUTO $\rightarrow$ PAL $\rightarrow$ SECAM $\rightarrow$ NTSC3.58 $\rightarrow$ NTSC4.43

11 TV/VIDEO button

Press to select the TV or one of the other input modes.

TV $\rightarrow$ $\odot$ -1 $\rightarrow$ $\odot$ - (RGB) $\rightarrow$ $\odot$ -2 $\rightarrow$ $\odot$ - (Y/C)

$\odot$ -1	Video signal through $\odot$ -1 (21-pin connector) is displayed on the screen.
$\odot$ -	RGB signal through $\odot$ -1 (21-pin connector) is displayed on the screen.
$\odot$ -2	Video signal through $\odot$ -2 (21-pin connector) is displayed on the screen.
$\odot$ -	S video signal through $\odot$ - (S video input connector) and $\odot$ -2 (21-pin connector) is displayed on the screen. When you use S video equipment, make sure that the set is in the S video mode.

S video input

Video signals may be separated into Y (luminance) and C (chrominance) signals.


Usually these two signals are combined in a VTR and output as one signal, and supplied to a TV.

Separation of the Y and C signals prevent them from interfering with one another, thereby improving picture quality.

This set is equipped with an S video input connector through which these separated signals can be input directly.

Connect the S video output connector on the VTR to the S video input on this set.

To operate the TV with the Commander, point it toward the remote control detector. The buttons used for teletext operation are indicated in light green. Buttons not referred to in this manual do not operate.



RM-684

1 mute button

Press to mute the sound.
Press again to restore the sound.

2 0-9 buttons

Use to select a programme or a channel number.

3 -/--- button

Use to select a programme number over 9.
To select 23, press -/---, then 2 and 3.

4 P/C (programme/channel) button

Use to select the channel tuning mode or to return to the programme tuning mode.

5 A/B bilingual button

Press to select channel A (usually the local language) or B (usually the original language) of a bilingual programme.

6 picture and sound adjustment buttons

There are two ways to use these buttons.

1. When watching a TV programme

Press repeatedly until the on-screen display of the required item appears, i.e. picture, colour, brightness, hue, sharpness, bass, treble or balance.
Adjust by pressing + or -.

2. When presetting TV channels

For details, please see "To preset channels".

7 reset button

Press to reset the picture and sound adjustment to the factory-set levels.

8 Preset button

Press to display a preset mode.

9 C (clear) button

Press to cancel a station memory content.

10 +/- Search button

Used when presetting channels.

11 standby button

Press to turn the set into the standby mode. Use this facility to turn off the set for short periods of time. To return to TV mode, press TV or the programme number on the Remote Commander.

12 TV button

Press to change to TV mode from standby, video input or teletext mode.

13 input button

Press to view the input picture coming in through the -1 connector.

Each time this button is pressed, -1 and -2 will appear alternately.
Press or the programme number to return to the TV mode.

14 input button

Press to view the input picture coming in through the -2 or -3 connectors. Each time this button is pressed, -2 and -3 will appear alternately.

Press or the programme number to return to the TV mode.

15 CATV button

Use to select CATV channels.

16 Time button

In TV mode, press to display the present time on the screen, and again to make it disappear. This function is available only when the teletext service is broadcast in the selected channel.

17 On-screen display button

Press to make the display appear on the screen.
Press again to make it disappear.

18 Volume +/- buttons

19 PROGR/C +/- buttons

Used to scan the available programmes or channels.

20 loudness button

Press to emphasize high and low tones. Press again to restore the normal sound. (The indicator on the screen is .)

21 space sound button

Press to obtain special acoustic effects. Press again to restore normal sound. (The indicator on the screen is .)

22 Noise reduction button

Press to reduce noise on the picture. The indicator on the set lights up.

23 TV system select button

Press to select the TV system.


B/G → L → I
↑

24 store button

Used when presetting channels.


1-2. PREPARATION FOR USE

- 1** Connect the aerial to the socket on the rear of the set.
This socket receives the standard 75-ohm aerial plug.
- 2** Connect the optional speakers to the speaker terminals on the rear of the set.
- 3** Plug in the set.
- 4** Insert two R6 batteries checking the correct polarity. See the illustration below.
- 5** Press power switch on the set.
- 6** Preset the available channels. (See "To Preset Channels".)



1-3. TO PRESET CHANNELS


Buttons used for presetting channels



You can preset a channel to a desired programme position. Use the buttons on the Remote Commander.


Example: Preset channel 32 to programme position 5.

- 1 Press $\rightarrow$ (preset). "P" flashes.




Press $\rightarrow$ button on the right hand side of the TV to set the colour system to AUTO. Press $\rightarrow$ on the Remote Commander to select the appropriate TV system.

- 3 Press P/C. "C" flashes.



- 4 Select a desired channel number by pressing a number button on the Remote Commander.

e.g. To tune in channel number 32, press 3 and then 2.
To tune in channel 4, press 0 and then 4.




If you don't know the channel number, tune in a higher or lower numbered station by pressing $\leftarrow$ +/- . Channel searching starts. The channel number increases or decreases until a TV station is tuned in.


To tune in a CATV channel, press $\rightarrow$, then select a desired channel number by pressing a number button.

Continued

- 5** If you want to give a station a name
Press .
The first position of the station name flashes.



Select a desired character by pressing +/-.
The numbers 0-9 and the letters A-Z will appear sequentially.



To make the second position flash, press again and select a desired character by pressing +/-.
Thus four characters can be displayed by repeating the steps above.
To make a position blank, leave as is.

When the last column flashes, press . "P" starts flashing.

- 6** After you have selected all the numbers and characters displayed on the screen, press to store the data.
"P" starts flashing.
If you want to preset more channels, repeat steps 2 to 6.

- 7** Press . The display will return to the previous state.

Note

- If you want to skip a certain programme position:
1 Press .
2 Select a programme position number to be skipped.
3 Press C and then .

The next time the programme +/- button is pressed, the programme position will be skipped.
If you want to skip more programme positions, repeat steps 2 and 3.

Note on colour system button ()

Normally, set to AUTO. If abnormal or no colour picture appears, press this button to select the system which produces normal colour.
The indications will appear as follows:

AUTO → PAL → SECAM → NTSC_{3.58} → NTSC_{4.43}

Note on TV system button ()

If the sound is distorted or noisy, press this button to select the system which produces clear sound.
The indications will appear as follows:


B/G → L → I

B/G: West European countries except France and the UK

L: France

I: UK

1-4. WATCHING TV PROGRAMMES




- 1** Press (POWER) switch on the set to turn the TV on.

- 2** Select a programme in one of the following two ways:

To select by programme position number

Press P/C to change into the programme tuning mode.

- (a) For direct programme tuning for the programme under 10, press 0, 1, 2, 3, ... 9.



- (b) For direct programme tuning for the programme over 9, press +/- and two number buttons.
(e.g. for programme 32, press +/-, 3 and then 2)

- (c) For sequential programme up/down tuning, press PROGR/C +/-.


Note

When pressing two number buttons, the second button should be pressed within 5 seconds. Otherwise the operation will be cancelled and the display will return to the original one.

To select by channel number

Press P/C to change into the channel tuning mode.

- (a) For direct channel tuning for normal channel, press two number buttons sequentially.
(e.g. for channel 2, press 0 and 2)
For CATV channels, press before pressing the number buttons.




Note

The second button should be pressed within 5 seconds. Otherwise the operation will be cancelled and the display will return to the original one.

- (b) For sequential channel up/down tuning, press PROGR/C +/-.

- 3** Press (volume) +/- buttons to adjust the volume.

1-5. CONNECTING OTHER EQUIPMENT



Notes

- Move the VTR away from the TV if the picture or sound is distorted.
- It is also possible to connect a VTR using the 1F socket.
- Computers which have RGB output only cannot be connected to 2.
- Do not connect VTRs to both 2 and S at the same time.

1-6. VIEWING TELETEXT

To view the teletext service, use the Remote Commander.
The buttons for teletext operation are indicated in green.

Operation

- 1 Select the TV channel for the desired teletext service. When the signal is weak, teletext errors may often occur.
- 2 Press (TEXT/MIX) to display the teletext service.
The teletext service can be displayed directly from the standby mode by pressing .
Once has been pressed, the TV channel cannot be changed.
- 3 Key in the three digits of the desired page using the number buttons. If an error is made, complete the three-digit sequence by keying in any digit.
Then re-enter the correct page number. The requested teletext page is displayed.

How to Activate Various Functions

To display the index page	Press (INDEX). If the necessary signal is not being broadcast, page 100 is displayed.
To access the next or preceding page	Press (PAGE+) or (PAGE-).
To superimpose the teletext display on the picture	Press twice from TV mode. Press again to return to the TEXT display.
To suppress the teletext display so that the TV picture is displayed.	Press (TEXT CL). This button can be operated from both the TEXT and MIX displays.
To prevent a teletext page (subpage) from being updated/changed	Press (HOLD). The HOLD symbol appears at the top of the screen.
To resume normal teletext reception	Press .
To enlarge the teletext display	Press once to enlarge the upper half of the display; press again to enlarge the lower half of the display. And press again to return to the normal display.
To reveal concealed information such as answers to a quiz	Press (REVEAL). Press again to conceal the answers.

To adjust the contrast of the teletext display

When in teletext mode, adjust by using the + or - buttons adjacent to the  button.

To watch the TV programme while waiting for a requested page to be displayed

- 1 Request the new page.
- 2 Press  to watch the TV programme.
The requested page number and other data appears at the top of the screen while the page number is being searched for. When the requested page has been captured, the page number remains on the screen and the other data disappears.

P101
(TV picture)

To view this page, press  / .

To have a requested page displayed at a pre-determined time

- 1 Request a time coded page (e.g. alarm page).
- 2 Press  (TP ON).
"T****" will appear at the bottom of the screen.

T****

- 3 Enter your request time with the number buttons, using four digits. For example, 0730.

T0730

To watch the TV programme until the requested time, press .
At the requested time, the page number will be displayed at the top of the screen.
To view this page, press  / .

To cancel the request, first ensure that the teletext page is displayed, then press  (TP OFF).

To return to the TV mode

Press  on the Remote Commander.

To receive the teletext service of a different TV channel

- 1 Press  to return to the TV mode.
- 2 Select the desired TV channel.
- 3 Press  / .

1-7. RECEIVABLE CHANNELS AND CHANNEL DISPLAYS

The following tables show the receivable channels and the corresponding indications for each TV and colour system.

Check the TV and colour system in your area, then

PAL B/G	
Receivable channel	Indication displayed on the screen
E 2	C 02
3	C 03
4	C 04
.....	
12	C 12
21	C 21
.....	
69	C 69
Italy	
A	C 13
B	C 14
C	C 15
D	C 16
E	C 17
F	C 18
G	C 19
H	C 20
H1	C 11
H2	C 12

Cable TV (1)	
Receivable channel	Indication displayed on the screen
S 1	 01
2	 02
.....	
41	 41

Cable TV (2)	
S 01	 42
.....	
S 05	 46
M1	 01
.....	
M10	 10
U 41	 11
.....	
U 10	 20

display the indication (in the right column) which corresponds to the channel (in the left column) you wish to view.

French SECAM-L	
Receivable channel	Indication displayed on the screen
2	C 02
3	C 03
.....	
10	C 10
21	C 21
.....	
69	C 69
French Cable TV	
B	 02
C	 03
D	 04
.....	
O	 15
P	 16
Q	 17

PAL-I Ireland	
Receivable channel	Indication displayed on the screen
A	C 501
B	C 02
C	C 03
D	C 04
E	C 05
F	C 06
G	C 07
H	C 08
J	C 09
PAL-I UK	
21	C 21
.....	
69	C 69

1-8. PRECAUTIONS

Safety


- Operate the set only on 220–240 V AC, 50 Hz.
- If the AC cord becomes damaged refer servicing to qualified personnel only.
- Should any liquid or solid object fall into the cabinet, unplug the set and have it checked by qualified personnel before operating it any further.
- Unplug the set from the wall outlet if it is not going to be used for several days or more. To disconnect the cord, pull it out by the plug. Never pull the cord itself.

Installation


- To prevent internal heat build-up, do not block the ventilation openings.
 - Do not install the set in a hot or humid place or in a place subject to excessive dust or mechanical vibration.
-

SECTION 2 DISASSEMBLY


2-1. H₁ BLOCK ASSY REMOVAL



2-2. A BOARD REMOVAL




2-3. PICTURE TUBE REMOVAL




2-4. REMOVAL OF ANODE CAP

• REMOVING PROCEDURES



• HOW TO HANDLE AN ANODE-CAP

- ① Don't hurt the surface of anode-caps with sharp shaped material!
- ② Don't press the rubber hardly not to hurt inside of anode-caps!
A metal fitting called as shatter-hook terminal is built in the rubber.
- ③ Don't turn the foot of rubber over hardly! The shatter-hook terminal will stick out or hurt the rubber.



SECTION 3
SET-UP ADJUSTMENTS

- The following adjustments should be made when a complete realignment is required or a new picture tube is installed.
- These adjustments should be performed with rated power supply voltage unless otherwise noted.

The control and switch below should be set as follows unless otherwise noted :

○ CONTRAST control 80% (or Normal by Commander)
✱ BRIGHTNESS control 50%

Perform the adjustments in order as follows :

1. Beam Landing
2. Convergence
3. Focus
4. White Balance

Note : Test Equipment Required.

1. Color Bar/Pattern Generator
2. Degausser
3. DC Power Supply
4. Digital multimeter
5. Oscilloscope

Preparation

- Set the side of the unit with the PICTURE TUBE so that it faces east or west in order to reduce the influence of external magnetic force.
- Turn the power switch for the unit ON and erase the magnetic force using a degausser.

3-1. BEAM LANDING

1. Position neck protector ass'y as shown in Fig. 3-1.
2. Input a raster signal with the pattern generator.
CONTRAST } normal
BRIGHTNESS }
3. Turn the raster signal of the pattern generator to red.
4. Move the deflection yoke backward, and adjust with the purity control so that red is in the center and blue and green are at the sides, evenly.
(Fig. 3-2. ~ 3-4.)
5. Move the deflection yoke forward, and adjust so that the entire screen becomes red, (Fig. 3-2.)
6. Switch over the raster signal to blue and green and confirm the condition.
7. When the position of the deflection yoke is determined, tighten it with a deflection yoke mounting screw.
8. When landing at the corners is not right, adjust by using the magnet. (Fig. 3-5.)

Fig. 3-1.




Fig. 3-2.




Fig. 3-3.




Fig. 3-4.





Fig. 3-5.




3-2. CONVERGENCE


Preparation :

- Before starting, perform FOCUS, H. SIZE and V. SIZE adjustments.
- Set BRIGHTNESS control to minimum.
- Feed in the dot pattern.



1. Horizontal and Vertical Static Convergence




- (1) Adjust H. STAT VR to coincide red, green and blue dots on the center of screen. (Horizontal movement)
- (2) Adjust V. STAT magnet to coincide red, green and blue dots on the center of screen. (Vertical movement)
- (3) If the red, green and blue dots do not coincide on the center of screen with H. STAT VR, perform horizontal convergence adjustment using H. STAT VR and V. STAT magnet as shown below.
(In this case, H. STAT VR and V. STAT magnet effect each other.)
- Tilt the V. STAT magnet and adjust static convergence to open or close the V. STAT magnet.




- (4) When the V. STAT magnet is moved in the direction of arrow ③ and ④, red, green and blue dots move as shown below.



2. Operation of BMC (Hexapole) Magnet



- The respective dot operations resulting from the operation of each magnet are not completely independent, so be sure to perform adjustment while tracking.
Use the H. STAT VR to adjust the red, green, and blue dots so they coincide at the center of screen (by moving the dots in the horizontal direction).



SECTION 4
CIRCUIT ADJUSTMENTS

3. Dynamic Convergence Adjustment

- Adjust the Y-CROSS (RV1705) and Y-BOW (RV1702), so that RED and BLUE shown in Fig3-6 will become $a=b=c$.




Fig. 3-6

- Match the horizontal convergence at the center of the screen with H STAT VR.
- Adjust the CORNER BOW (RV1703), so that RED and BLUE shown in Fig3-7 will become $a=b=c$ and $d=e=f$.

Note: At this point, if the relationship between $a=c$ or $d=f$ is not established, adjust the Y-CROSS (RV1705) again.




Fig. 3-7

- Match the horizontal convergence at the center of the screen with the H STAT VR.
- Adjust the H TILT (RV1701) so that the RED and BLUE shown in Fig3-8 will become $a=b$.




Fig. 3-8

- Adjust the H AMP (RV1704) so that the RED and BLUE shown in Fig3-9 will become $b=c$.






Fig. 3-9

- Match the horizontal convergence at the center of the screen with the H STAT VR.
- When the H AMP is adjusted repeat the procedures described in Steps (5) to (7).
- If divergence of the convergence exists at the corner of the screen, the adjustments described in Steps after (3) should be repeated.

4. Screen-corner Convergence



3-3. WHITE BALANCE

[Screen (G2) Setting]


- Input dot signals from the pattern generator.
- Set the picture BRIGHTNESS control to the minimum level.
- Apply 180 Vdc to the cathodes of R, G, and B from an external power source.
- While watching the picture, adjust the G2 volume (RV701) immediately before the fly-back line disappears.

[White Balance Adjustment]

- Input all-white signals from the pattern generator.
- Adjust the BRIGHTNESS and COLOR controls to the standard level.
- Adjust the white balance using RV704 (B DRIVE) and RV703 (G DRIVE).

In the following adjustments, the CONTRAST COLOR and BRIGHTNESS controls are set to normal unless otherwise specified.

4-1. A BOARD ADJUSTMENT




(Component side)

TUNER AGC Adjustment

- Tune in an off-air signal.
- Adjust AGC VR on IFD389 so that snow-noise and cross-modulation just disappear from the picture.

4-2. B BOARD ADJUSTMENTS



(Component side)

REC OSC NTSC 3.58 MHz Adjustment (CT331)


- Input a NTSC 3.58 MHz COLOR BAR pattern.
- Short circuit between pin ① of IC331 and ground.
- Adjust CT331 to get the slowest movings of picture.
- Remove the jumper wire from IC331.

REF OSC Adjustment NTSC 4.43 MHz Adjustment (CT332)


- Input a NTSC 4.43 MHz COLOR BAR pattern.
- Short circuit between pin ① of IC331 and ground.
- Adjust CT332 to get the slowest movings of picture.
- Remove the jumper wire from IC331.

1H DELAY LINE Adjustment (L332, RV331)

- Input PAL COLOR BAR pattern.
- Connect the oscilloscope to pin ① (R-Y) of IC331.
- Adjust L332 to minimize the double waveform outline.



- Input a TEST COLOR BAR pattern.
- Rotate the RV331 control and adjust till the ANT PAL of the waveform part matches the 0 level.




- L332 and RV331 affect each other. Repeat till the conditions of both meet.

SECAM ID Adjustment (L335)

- Input a SECAM COLOR BAR pattern.
- Connect a Digital Multimeter at pin ② of IC331.
- Adjust L335 so that the indicator goes up to the maximum.


BELL FILTER Adjustment (T331)

- Input a SECAM COLOR BAR pattern.
- Connect an oscilloscope to the Q335 emitter.
- Adjust T331 so that the waveform becomes flat.
- L335 and T331 tracking adjustment is required.



SECAM DISCRI Adjustment (L333, L334)

1. Input a SECAM COLOR BAR pattern.
2. Connect an oscilloscope to pin ① of IC331.
3. Adjust L333 so that white and black parts of the waveform of pin ① becomes 0 level.
4. Connect an oscilloscope to pin ③ of IC331.
5. Adjust L334 so that white and black part of the waveform of pin ③ becomes 0 level.

**4.25 TRAP Adjustment (L336)**



1. Input SECAM COLOR BAR pattern.
2. Connect oscilloscope to the Q307 emitter.
3. Adjust L336 so that 4.25 MHz waveform to minimum.

4.43 TRAP Adjustment (L337)












1. Input SECAM COLOR BAR pattern.
2. Connect oscilloscope to the Q307 emitter.
3. Adjust L337 so that 4.43 MHz waveform to minimum.

SUB BRT Adjustment (RV301)

1. Set BRIGHTNESS = 50%
COLOR = 50%
CONTRAST = Minimum
2. Adjust RV301 (SUB BRIGHT) so that the blue stripe portion on the color-bar pattern signal is bright dimly.

**4-3. D BOARD ADJUSTMENT****H. PHASE Adjustment (RV502)**


1. Input a PAL COLOR BAR pattern.
2. Set the CONTRAST and BRIGHTNESS controls to the standard positions.
3. Set RV1508 (H. CENT) to the mechanical center position.
4. Connect an oscilloscope to pin ⑩ (SPC OUT) of IC501.
5. Rotate RV502 and adjust Block T to $4.9 \pm 0.1 \mu s$.

**RV1504****H.SIZE (HORIZONTAL SIZE)****RV1507****V.SIZE (VERTICAL SIZE)****RV1508****H.CENT (HORIZONTAL CENTER)****RV1506****V.CENT (VERTICAL CENTER)****RV1509****V.ANGLE (VERTICAL ANGLE)****RV1503****PIN AMP (PINCUSHION AMPLIFIER)****RV1502****PIN PHASE (PINCUSHION PHASE)****RV1501****PIN COR (PINCUSHION CORRECT)****RV1505****CORNER COR (CORNER CORRECT)****4-4. V BOARD ADJUSTMENTS****CLOCK Adjustment (CT01)**

1. Disconnect V-1 connector.
2. Connect frequency counter to pin ⑨ of IC03.
3. Adjust CT01 to 6.0 MHz ± 50 Hz.
4. Connect V-1 connector.

PICTURE LEVEL Adjustment (RV01)

1. Connect oscilloscope to G output of V-7 connector.
2. Adjust RV01 so that G output level (black level to white peak) is $2.8 \pm 0.05V$.




KV-D3421D
RM-684/SS-XT291

KV-D3421D
RM-684/SS-XT291



SECTION 5 DIAGRAMS


5-1. BLOCK DIAGRAMS (1)



A (TUNER, VIF, SIF, SYSTEM SW
AUDIO SW.)

B CHROMA DECODER
R-G-B INTERFACE
AV SW. VIDEO NR









5-2. BLOCK DIAGRAMS (2)

KV-D3421D
RM-684/SS-XT291

KV-D3421D
RM-684/SS-XT291





F


(POWER SUPPLY)

H1

(SIRCS, RECEIVER, INDICATOR)

H2

(CONTROL SWITCH)

5-3. CIRCUIT BOARDS LOCATION**5-4. SCHEMATIC DIAGRAMS AND PRINTED WIRING BOARDS — Conductor Side —**

Note: The components identified by shading and mark  are critical for safety. Replace only with part number specified.

Note:


- All capacitors are in μF unless otherwise noted. $p\mu\text{F}$ 50WV or less are not indicated except for electrolytic and tantalums.
- Electrolytic capacitors with resisting pressure are not indicated.
- All resistors are in ohms.
 $k\Omega = 1000\Omega$, $M\Omega = 1000k\Omega$
- Indication of resistance, which does not have one for rating electrical power, is as follows.

Pitch: 5 mm
Rating electrical power: 1/4W

-  : nonflammable resistor.
- Δ : internal component.
-  : panel designation or adjustment for repair.
- All variable and adjustable resistors have characteristic curve B, unless otherwise noted.
- Readings are taken with a color-bar signal input.
no mark : PAL
< > : SECAM
() : NTSC 3.58MHz
[] : NTSC 4.43MHz
- Readings are taken with a 10M Ω digital multimeter.
- Voltages are dc with respect to ground unless otherwise noted.
- Voltage variations may be noted due to normal production tolerances.
- All voltages are in V.
- $\times$: Can not be measured.
- Circled numbers are waveform references.
- : B + bus.
- - - : B - bus.
- $\Rightarrow$: signal path.

Reference information

RESISTOR	: RN	METAL FILM
	: RC	SOLID
	: FPRD	NONFLAMMABLE CARBON
	: FUSE	NONFLAMMABLE FUSIBLE
	: RS	NONFLAMMABLE METAL OXIDE
	: RB	NONFLAMMABLE CEMENT
	: RW	NONFLAMMABLE WIREWOUND
	: *	ADJUSTMENT RESISTOR
COIL	: LF-8L	MICRO INDUCTOR
CAPACITOR	: TA	TANTALUM
	: PS	STYROL
	: PP	POLYPROPYLENE
	: PT	MYLAR
	: MPS	METALIZED POLYESTER
	: MPP	METALIZED POLYPROPYLENE
	: ALB	BIPOLAR
	: ALT	HIGH TEMPERATURE
	: ALR	HIGH RIPPLE

— F BOARD —

(TUNER, VIF, SIF, SYSTEM SW, AUDIO SW)

KV-D3421D
RM-684/SS-XT291

(TUNING CONTROL,
AUDIO CONTROL, AUDIO OUT)






The circuit indicated as left contains high voltage of over 600 Vp-p. Care must be paid to prevent an electric shock in inspection or repairing.

The image shows a top-down view of a Sony electronic circuit board, specifically a television set. The board is densely packed with components and features a complex layout of printed circuit traces. Key elements include:


- Top Left:** The Sony logo and the model number "627-727-13".
- Central Area:** A large integrated circuit (IC) is prominently displayed, surrounded by numerous resistors (labeled R101, R102, etc.) and capacitors (labeled C101, C102, etc.).
- Right Side:** A vertical strip of components, possibly a connector or a series of ICs, is visible.
- Bottom Section:** A horizontal strip of components, likely a power supply or a series of ICs, is located at the bottom.
- Traces:** A dense network of white printed circuit traces connects the various components across the board.
- Labels:** Numerous alphanumeric labels are scattered across the board, identifying specific components and their locations.

S-78 ▲ 091







WAVEFORMS J BOARD




WAVEFORMS D BOARD



D BOARD IC501 TEA2028B




D BOARD IC1501 TEA2031A



DJUNGL, 50/60 SW.
PIN AMP, H-V OUT.
(COMPARATOR)


WAVEFORMS C BOARD




KV-D3421D
RM-684/SS-XT291

J (AV INTERFACE)

- J BOARD -



IC		D511	G-2
IC501	I-8	D512	G-2
IC502	G-3	D513	G-2
IC503	G-1	D591	H-5
IC1501	B-4	D592	H-5
IC1701	F-1		
		D593	H-5
IC1702	D-1	D801	G-11
IC1704	E-4	D802	C-10
		D803	F-10
		D804	F-7
TRANSISTOR			
Q501	I-6	D805	F-7
Q502	H-8	D806	E-11
Q503	G-5	D807	D-10
Q505	G-2	D808	B-10
Q506	H-2	D809	D-7
Q507	J-4	D850	B-12
Q509	I-4	D1501	A-6
Q510	I-4	D1502	B-5
Q512	G-9	D1503	B-5
Q513	G-3	D1504	B-5
Q514	G-8	D1505	A-5
Q591	H-6	D1515	D-1
Q592	J-4	D1550	H-11
Q598	H-5	D1552	B-8
Q804	E-13	D1553	H-12
Q805	G-12	D1652	I-2
Q806	C-7	D1701	E-4
Q807	C-7	D1702	D-5
Q1551	B-6	D1703	D-4
Q1552	A-6	D1704	D-4
Q1608	H-11	D1705	D-4
Q1609	H-11	D1706	C-4
Q1610	H-12	D1707	E-2
Q1613	H-11	D1708	D-1
Q1653	I-3	D1709	C-1
		D1710	B-2
Q1701	E-2		
Q1703	E-4		
Q1704	E-3		
Q1705	C-3		
Q1706	C-4		
Q1707	E-2		
Q1708	E-1		
Q1709	C-1		
Q1710	C-1		
Q1711	B-3		
Q1712	C-3		
Q1716	B-1		
Q1717	D-2		
DIODE			
D501	I-9		
D502	J-3		
D504	G-2		
D506	H-8		
D508	J-5		
		RV502	I-9
		RV1501	A-4
		RV1502	A-3
		RV1503	A-3
		RV1504	A-5
		RV1505	A-5
		RV1506	A-2
		RV1507	A-2
		RV1508	A-2
		RV1509	A-3
		RV1701	B-1
		RV1702	B-1
		RV1703	B-2
		RV1704	B-2
		RV1705	B-2



KV-D3421D
RM-684/SS-XT291


KV-D3421D
RM-684/SS-XT291

J (AV INTERFACE)


VM (VM AMP)

C (R.G.B OUT)


- J BOARD -




- VM BOARD -




- C BOARD -









WAVEFORMS B BOARD



- B BOARD IC301 TDA4580



• B BOARD IC331 TDA4555



As to the voltage value shown by the mark ✖ on the Schematic Diagram, see the another list.


	PAL	SECAM	NTSC3.58	NTSC4.43	S VIDEO
Q331 (B)	0V	5.4V	0V	0V	5.3V
Q332 (B)	0V	0V	5.9V	0V	5.9V
Q333 (C)	5V	12.4V	12.3V	0V	12.4V
Q334 (B)	4.6V	0V	0V	4.9V	0V
Q1351 (C)	5.7V	0V	0V	0V	0V
IC1311 ③	0V	0V	2.7V	0V	3.4V
IC1312 ③	0V	0V	0V	0V	3V
IC1313 ③	0V	0V	2.7V	0V	3.4V
IC331 ⑤	6.4V	4.2V	6V	5.7V	5.7V
IC331 ⑦	6.3V	4.2V	5.8V	5.4V	5.4V
IC331 ⑩	5.8V	5.8V	7.6V	7.7V	3.4V
IC331 ⑪	8.1V	7V	5.7V	5.8V	5.7V
IC331 ⑫	-0.1V	0.1V	5.9V	0.1V	5.9V

KV-D3421D
RM-684/SS-XT291


KV-D3421D
RM-684/SS-XT291

B (R.G.B INTERFACE, AV SW,
CHROMA RECORDER, SHARPNESS CONTROL)

- B BOARD -




IC		Q1361 F-10	
1301	I-9	1363	E-10
1302	E-6		
1306	E-9		
1310	G-9		
1311	H-3		
1312	E-3		
1313	G-3		
	F-2		
	I-2		
DIODE		ADJ	
0301	J-6	CT331	F-7
303	I-6	CT332	F-7
304	I-11	RV301	A-10
305	I-10	RV331	D-7
306	H-3		
307	I-5		
308	G-2		
309	H-3		
310	H-4		
311	H-2		
313	H-2		
314	I-7		
316	H-6		
317	D-1		
318	H-5		
319	H-5		
320	E-10		
331	E-5		
333	E-5		
337	G-9		
TRANSISTOR			
Q301	I-6		
302	G-2		
303	J-6		
304	J-7		
305	J-8		
306	E-4		
307	I-3		
308	G-3		
311	H-10		
312	H-7		
313	H-7		
316	H-7		
331	F-5		
332	F-8		
333	F-8		
334	F-5		
335	F-5		
336	G-2		
337	G-4		
338	G-4		
339	G-5		
340	H-4		
341	I-3		
342	H-9		
343	G-10		
344	G-10		
346	G-11		
347	G-10		
348	G-10		
349	G-10		
350	G-9		
351	F-10		
352	H-6		
353	H-5		
355	H-5		
381	I-5		
1351	C-5		
1352	C-5		
1353	D-5		
1354	D-5		
1360	F-3		



① 3 V_{p-p} (4MHz)	② 0.6 V_{p-p} (8.75MHz)
③ 1.5 V_{p-p} (H)	④ 1.3 V_{p-p} (H)
⑤ 4.6 V_{p-p} (V)	⑥ 0.36 V_{p-p} (6MHz)

5-5. SEMICONDUCTORS


BX-1398




CX20125
LA7016




CXA1114P
MAB8641P-W136
SAA5231
TDA4555
TDA4580
TDA6200
TEA2028B
PD4364CX-15L




LM1875T



NJM7812FA
PC78M05H




SAA5234E




STR-S5941
PC4570HA




TBA129
TEA2014A
TEA2031A
PC393C




TC4052BP




PC574J




SAB3036




PCD8582




HIC2110



HCF0050A



TDA8170




STR90120




BF199
2SA1091
2SC2060



DTA114ES
DTA144ES
DTC114ES
DTC124ES
DTC144ES



2SA1175
2SC2785



2SA1221
2SB734
2SC2958-K
2SD773
2SC4159
2SD774




2SC2275
2SC3317




2SC2611
2SC2688



2SC3298B
2SD1761




2SD1941-07




2SD2096




CTU-12S




ERD29-08J




EU2Z
GP08D
RGP01-17
RGP10G
RGP15G
RGP15J
RU4Z-K2




ERB81-004
ERC06-1SS
ED38-06
RH-1CV1
S1B01-02




KBU4JL-6088




MC931



RD3.6ES-B1
RD3.9ES-L1
RD4.7ES-B2
RD5.1ES-B1
RD5.6ES-B2
RD6.2ES-B3
RD9.1ES-B3
RD11ES-B3
RD13ES-B2
1SS119



TLR124
LD201VR



SECTION 6
EXPLODED VIEWS


NOTE:

- Items with no part number and no description are not stocked because they are seldom required for routine service.
- The construction parts of an assembled part are indicated with a collation number in the remark column.
- Items marked "*" are not stocked since they are seldom required for routine service. Some delay should be anticipated when ordering these items.

The components identified by shading and mark Δ are critical for safety.
Replace only with part number specified.

6-1. CHASSIS

- BVTP4×16 7-685-633-79
- BVTP3×12 7-685-648-79
- BVTP3×16 7-685-650-79




REF. NO.	PART NO.	DESCRIPTION
1	*A-1347-042-A	V BOARD, COMPLETE
2	*A-1135-615-A	B BOARD, COMPLETE
3	*A-1296-678-A	A BOARD, COMPLETE
4	4-386-618-01	RIVET, T TYPE
5	*A-1385-065-A	K BOARD, COMPLETE
6	*A-1388-117-A	J BOARD, COMPLETE
7	4-393-214-01	BRACKET, J
8	4-319-520-11	SCREW, SPECIAL (-PW4X30)

REF. NO.	PART NO.	DESCRIPTION
9	Δ 1-439-418-51	TRANSFORMER ASSY FLYBACK (NX-1618)
10	Δ 4-389-778-01	HOLDER, AC CORD
11	*A-1345-857-A	D BOARD, COMPLETE
12	Δ 1-574-745-11	CORD, POWER (WITH CONNECTOR)
13	*A-1245-463-A	F BOARD, COMPLETE
14	X-4392-411-2	COVER ASSY, REAR
15	X-4374-104-1	SCREW (B) ASSY, ORNAMENTAL
16	Δ 1-465-059-11	TUNER, BT (UV-616S)

6-2. PICTURE TUBE

- BVTP4×16 7-685-633-79
- BVTP3×12 7-685-648-79



The components identified by shading and mark Δ are critical for safety.
Replace only with part number specified.

REF. NO.	PART NO.	DESCRIPTION	REMARK	REF. NO.	PART NO.	DESCRIPTION	REMARK
51	X-4393-204-6	BEZEL ASSY	52	69	*A-1330-967-A	C BOARD, COMPLETE	
52	X-4393-201-3	PLATE ASSY, ORNAMENTAL		70	4-383-181-01	BRACKET (B), PICTURE TUBE	
53	4-393-207-01	BUTTON, POWER		71	4-383-180-01	BRACKET (A), PICTURE TUBE	
54	4-329-112-00	SPRING		72	X-4393-203-1	CABINET ASSY	62, 70, 71
55	*4-392-437-01	BRACKET, H4		73	*4-376-036-01	SPRING, TENSION	
56	*4-388-955-01	BRACKET (B), LIGHT GUIDE		74	*1-630-234-11	H2 BOARD	
57	*4-374-987-01	GUIDE, LIGHT		75	X-4393-202-1	BRACKET ASSY, H2	
58	*1-630-233-11	H1 BOARD		76	Δ 1-426-433-11	COIL, DEMAGNETIZATION	
59	*4-393-206-01	COVER, PROTECTION		77	4-385-452-01	CLOTH	
60	4-392-429-01	SHAFT, AC		78	*4-371-629-01	STOPPER, WIRE	
61	Δ 1-571-877-11	SWITCH, PUSH (AC POWER)		79	4-306-034-00	FLANGE NUT, (B) 5MM	
62	4-319-520-11	SCREW, SPECIAL (-PW4X30)		80	*4-387-216-01	HOLDER, LEAD	
63	*4-387-204-01	NUT, SPECIAL, PICTURE TUBE		81	4-308-870-00	CLIP LEAD WIRE	
64	Δ 8-733-721-05	PICTURE TUBE (A80JYV10X)		82	1-452-032-00	MAGNET, DISK; 10MM ϕ	
65	3-703-961-01	SPACER, DY		83	1-452-094-00	MAGNET, ROTATABLE DISK; 15MM ϕ	
66	*A-1342-088-A	VM BOARD, COMPLETE		84	X-4306-312-0	PERMALLOY ASSY, CONVERGENCE	
67	Δ 1-451-315-11	DEFLECTION YOKE (Y34FXA)		85	3-677-825-01	BAND, BINDING	
68	Δ 1-452-468-11	NECK ASSY, PICTURE TUBE (NA321)					

SECTION 7

ELECTRICAL PARTS LIST

KV-D3421D
RM-684/SS-XT291

B

NOTE:

The components identified by shading and mark A are critical for safety.

Replace only with part number specified.

• Items marked "A" are not stocked since they are seldom required for routine service. Some delay should be anticipated when ordering these items.

• All variable and adjustable resistors have characteristic curve B, unless otherwise noted.

RESISTORS

- All resistors are in ohms
- F : nonflammable

When indicating parts by reference number, please include the board name.

CAPACITORS

• MF : μ F, PF : μ F

COILS

• MMH : mH, UH : μ H

REF. NO.	PART NO.	DESCRIPTION				REMARK	REF. NO.	PART NO.	DESCRIPTION				REMARK
*A-1135-615-A B BOARD, COMPLETE													

<CAPACITOR>													
C301	1-136-165-00	MYLAR	0.1MF	10%	50V		C349	1-136-173-00	FILM	0.47MF	5%	50V	
C302	1-136-165-00	MYLAR	0.1MF	10%	50V		C350	1-136-161-00	MYLAR	0.047MF	10%	50V	
C303	1-126-101-11	ELECT	100MF	20%	16V		C351	1-136-157-00	MYLAR	0.022MF	10%	50V	
C304	1-136-165-00	MYLAR	0.1MF	10%	50V		C352	1-136-157-00	MYLAR	0.022MF	10%	50V	
C305	1-124-119-00	ELECT	330MF	20%	16V		C353	1-102-963-00	CERAMIC	33PF	5%	50V	
C306	1-124-902-00	ELECT	0.47MF	20%	50V		C354	1-102-074-00	CERAMIC	0.001MF	10%	50V	
C307	1-124-902-00	ELECT	0.47MF	20%	50V		C355	1-102-816-00	CERAMIC	120PF	5%	50V	
C308	1-124-902-00	ELECT	0.47MF	20%	50V		C356	1-101-004-00	CERAMIC	0.01MF	50V		
C309	1-124-902-00	ELECT	0.47MF	20%	50V		C357	1-102-965-00	CERAMIC	39PF	5%	50V	
C310	1-136-165-00	MYLAR	0.1MF	10%	50V		C358	1-101-004-00	CERAMIC	0.01MF	50V		
C311	1-136-165-00	MYLAR	0.1MF	10%	50V		C359	1-124-963-11	ELECT	33MF	20%	16V	
C312	1-124-902-00	ELECT	0.47MF	20%	50V		C360	1-124-963-11	ELECT	33MF	20%	16V	
C313	1-124-902-00	ELECT	0.47MF	20%	50V		C361	1-101-004-00	CERAMIC	0.01MF	50V		
C314	1-124-902-00	ELECT	0.47MF	20%	50V		C364	1-101-361-00	CERAMIC	150PF	5%	50V	
C315	1-124-499-11	ELECT	1MF	20%	50V		C366	1-124-360-00	ELECT	1000MF	20%	16V	
C316	1-101-004-00	CERAMIC	0.01MF	50V		C368	1-102-944-00	CERAMIC	7PF	0.5PF	50V		
C317	1-102-953-00	CERAMIC	18PF	5%	50V		C369	1-102-944-00	CERAMIC	7PF	0.5PF	50V	
C318	1-124-477-11	ELECT	47MF	20%	16V		C370	1-102-944-00	CERAMIC	7PF	0.5PF	50V	
C319	1-126-101-11	ELECT	100MF	20%	16V		C371	1-102-944-00	CERAMIC	7PF	0.5PF	50V	
C320	1-124-477-11	ELECT	47MF	20%	16V		C374	1-124-477-11	ELECT	47MF	20%	16V	
C321	1-126-103-11	ELECT	470MF	20%	16V		C376	1-102-978-00	CERAMIC	220PF	5%	50V	
C322	1-102-953-00	CERAMIC	18PF	5%	50V		C377	1-101-888-00	CERAMIC	68PF	5%	50V	
C323	1-124-477-11	ELECT	47MF	20%	16V		C379	1-126-320-11	ELECT	10MF	20%	16V	
C324	1-124-477-11	ELECT	47MF	20%	16V		C380	1-124-963-11	ELECT	33MF	20%	16V	
C326	1-101-004-00	CERAMIC	0.01MF	50V		C381	1-124-925-11	ELECT	2.2MF	20%	50V		
C327	1-101-004-00	CERAMIC	0.01MF	50V		C382	1-124-927-11	ELECT	4.7MF	20%	50V		
C328	1-102-973-00	CERAMIC	100PF	5%	50V		C384	1-124-477-11	ELECT	47MF	20%	16V	
C329	1-124-499-11	ELECT	1MF	20%	50V		C385	1-124-927-11	ELECT	4.7MF	20%	50V	
C330	1-101-004-00	CERAMIC	0.01MF	50V		C386	1-136-165-00	MYLAR	0.1MF	10%	50V		
C331	1-126-101-11	ELECT	100MF	20%	16V		C397	1-126-101-11	ELECT	100MF	20%	16V	
C332	1-124-360-00	ELECT	1000MF	20%	16V		C399	1-126-101-11	ELECT	100MF	20%	16V	
C333	1-101-005-00	CERAMIC	0.022MF	50V		C401	1-102-947-00	CERAMIC	10PF	0.5PF	50V		
C334	1-101-884-00	CERAMIC	56PF	5%	50V		C402	1-102-935-00	CERAMIC	2PF	0.25PF	50V	
C335	1-101-006-00	CERAMIC	0.047MF	50V		C413	1-101-004-00	CERAMIC	0.01MF	50V			
C336	1-136-153-00	MYLAR	0.01MF	10%	50V		C414	1-124-477-11	ELECT	47MF	20%	16V	
C337	1-101-004-00	CERAMIC	0.01MF	50V		C415	1-124-963-11	ELECT	33MF	20%	16V		
C338	1-101-888-00	CERAMIC	68PF	5%	50V		C417	1-102-949-00	CERAMIC	12PF	5%	50V	
C339	1-102-816-00	CERAMIC	120PF	5%	50V		C418	1-102-947-00	CERAMIC	10PF	0.5PF	50V	
C340	1-102-953-00	CERAMIC	18PF	5%	50V		C419	1-102-949-00	CERAMIC	12PF	5%	50V	
C341	1-102-978-00	CERAMIC	220PF	5%	50V		C420	1-101-005-00	CERAMIC	0.022MF	50V		
C342	1-102-953-00	CERAMIC	18PF	5%	50V		C421	1-101-005-00	CERAMIC	0.022MF	50V		
C343	1-102-816-00	CERAMIC	120PF	5%	50V		C422	1-101-005-00	CERAMIC	0.022MF	50V		
C344	1-101-888-00	CERAMIC	68PF	5%	50V		C423	1-101-004-00	CERAMIC	0.01MF	50V		
C345	1-102-978-00	CERAMIC	220PF	5%	50V		C424	1-101-004-00	CERAMIC	0.01MF	50V		
C347	1-124-499-11	ELECT	1MF	20%	50V		C425	1-102-973-00	CERAMIC	100PF	5%	50V	
C348	1-124-499-11	ELECT	1MF	20%	50V		C426	1-124-499-11	ELECT	1MF	20%	50V	
							C427	1-126-233-11	ELECT	22MF	20%	50V	
							C428	1-102-074-00	CERAMIC	0.001MF	10%	50V	
							C431	1-124-963-11	ELECT	33MF	20%	16V	
							C1303	1-124-963-11	ELECT	33MF	20%	16V	
							C1319	1-126-101-11	ELECT	100MF	20%	16V	

B

REF. NO.	PART NO.	DESCRIPTION	REMARK
C1321	1-102-074-00	CERAMIC 0.001MF	10% 50V
C1383	1-124-477-11	ELECT 47MF	20% 16V
C1384	1-124-477-11	ELECT 47MF	20% 16V
C1385	1-124-477-11	ELECT 47MF	20% 16V
C1386	1-124-477-11	ELECT 47MF	20% 16V
C1387	1-124-477-11	ELECT 47MF	20% 16V
C1389	1-124-477-11	ELECT 47MF	20% 16V
C1390	1-124-477-11	ELECT 47MF	20% 16V
C1391	1-123-875-11	ELECT 10MF	20% 50V
C1392	1-102-978-00	CERAMIC 220PF	5% 50V
C1393	1-101-884-00	CERAMIC 56PF	5% 50V
<CONNECTOR>			
CN81	*1-564-506-11	PLUG, CONNECTOR 3P	
CN82	*1-564-509-11	PLUG, CONNECTOR 6P	
CN85	*1-566-659-11	CONNECTOR, HINGE (SOCKET) 18P	
CN86	*1-566-659-11	CONNECTOR, HINGE (SOCKET) 18P	
CN87	*1-564-505-11	PLUG, CONNECTOR 2P	
CN88	*1-564-509-11	PLUG, CONNECTOR 6P	
<COMPOSITION CIRCUIT BLOCK>			
CP302	1-232-096-00	COMPOSITION CIRCUIT BLOCK	
<TRIMMER>			
CT331	1-141-181-11	CAP. TRIMMER	
CT332	1-141-181-11	CAP. TRIMMER	
<DIODE>			
D301	8-719-911-19	DIODE 1SS119	
D303	8-719-911-19	DIODE 1SS119	
D304	8-719-911-19	DIODE 1SS119	
D305	8-719-911-19	DIODE 1SS119	
D306	8-719-911-19	DIODE 1SS119	
D307	8-719-110-23	DIODE RD11ES-B3	
D308	8-719-911-19	DIODE 1SS119	
D309	8-719-911-19	DIODE 1SS119	
D310	8-719-911-19	DIODE 1SS119	
D311	8-719-911-19	DIODE 1SS119	
D313	8-719-911-19	DIODE 1SS119	
D314	8-719-911-19	DIODE 1SS119	
D316	8-719-110-18	DIODE RD10ES-B3	
D317	8-719-911-19	DIODE 1SS119	
D318	8-719-911-19	DIODE 1SS119	
D319	8-719-911-19	DIODE 1SS119	
D320	8-719-911-19	DIODE 1SS119	
D331	8-719-911-19	DIODE 1SS119	
D333	8-719-911-19	DIODE 1SS119	
D337	8-719-109-93	DIODE RD6.2ES-B2	
<DELAY LINE>			
DL331	1-415-122-31	DELAY LINE, 1H (PAL)	
<IC>			
IC301	8-759-923-81	IC TDA4580	
IC331	8-759-947-20	IC TDA4555-V8	
IC1301	1-235-534-11	CONTROL MODULE, PICTURE	
IC1302	8-752-012-51	IC CX20125	
IC1306	8-759-800-81	IC LA7016	

REF. NO.	PART NO.	DESCRIPTION	REMARK
IC1310	1-464-932-31	FILTER BLOCK, COM (CFB-3)	
IC1311	8-759-800-81	IC LA7016	
IC1312	8-759-800-81	IC LA7016	
IC1313	8-759-800-81	IC LA7016	
<COIL>			
L301	1-410-466-41	INDUCTOR 4.7UH	
L302	1-410-466-41	INDUCTOR 4.7UH	
L304	1-410-470-11	INDUCTOR 10UH	
L305	1-408-416-00	INDUCTOR 39UH	
L306	1-410-470-11	INDUCTOR 10UH	
L307	1-410-470-11	INDUCTOR 10UH	
L308	1-410-470-11	INDUCTOR 10UH	
L309	1-410-470-11	INDUCTOR 10UH	
L310	1-408-413-00	INDUCTOR 22UH	
L311	1-410-470-11	INDUCTOR 10UH	
L312	1-408-419-00	INDUCTOR 68UH	
L331	1-408-408-00	INDUCTOR 8.2UH	
L332	1-404-539-11	COIL	
L333	1-404-554-11	COIL	
L334	1-404-554-11	COIL	
L335	1-404-554-11	COIL	
L336	1-404-495-00	COIL	
L337	1-404-495-00	COIL	
L338	1-410-470-11	INDUCTOR 10UH	
L339	1-410-478-11	INDUCTOR 47UH	
L342	1-410-470-11	INDUCTOR 10UH	
L344	1-410-470-11	INDUCTOR 10UH	
L405	1-410-470-11	INDUCTOR 10UH	
L411	1-410-466-41	INDUCTOR 4.7UH	
L1309	1-408-427-00	INDUCTOR 330UH	
<NR PACK>			
NRP301	1-466-181-11	NR PACK (NRP-2E)	
<TRANSISTOR>			
Q301	8-729-119-76	TRANSISTOR 2SA1175-HFE	
Q302	8-729-119-78	TRANSISTOR 2SC2785-HFE	
Q303	8-729-119-78	TRANSISTOR 2SC2785-HFE	
Q304	8-729-900-89	TRANSISTOR DTC144ES	
Q305	8-729-900-36	TRANSISTOR DTC124ES	
Q306	8-729-119-78	TRANSISTOR 2SC2785-HFE	
Q307	8-729-119-76	TRANSISTOR 2SA1175-HFE	
Q308	8-729-119-78	TRANSISTOR 2SC2785-HFE	
Q311	8-729-119-78	TRANSISTOR 2SC2785-HFE	
Q312	8-729-119-78	TRANSISTOR 2SC2785-HFE	
Q313	8-729-119-78	TRANSISTOR 2SC2785-HFE	
Q316	8-729-119-78	TRANSISTOR 2SC2785-HFE	
Q331	8-729-119-78	TRANSISTOR 2SC2785-HFE	
Q332	8-729-900-36	TRANSISTOR DTC124ES	
Q333	8-729-900-36	TRANSISTOR DTC124ES	
Q334	8-729-119-78	TRANSISTOR 2SC2785-HFE	
Q335	8-729-119-78	TRANSISTOR 2SC2785-HFE	
Q336	8-729-900-89	TRANSISTOR DTC144ES	
Q337	8-729-900-80	TRANSISTOR DTC114ES	
Q338	8-729-900-61	TRANSISTOR DTA114ES	
Q339	8-729-900-80	TRANSISTOR DTC114ES	
Q340	8-729-119-78	TRANSISTOR 2SC2785-HFE	
Q341	8-729-119-78	TRANSISTOR 2SC2785-HFE	
Q342	8-729-119-78	TRANSISTOR 2SC2785-HFE	
Q343	8-729-119-78	TRANSISTOR 2SC2785-HFE	

REF. NO.	PART NO.	DESCRIPTION	REMARK
Q344	8-729-119-78	TRANSISTOR 2SC2785-HFE	
Q346	8-729-119-76	TRANSISTOR 2SA1175-HFE	
Q347	8-729-119-78	TRANSISTOR 2SC2785-HFE	
Q348	8-729-119-78	TRANSISTOR 2SC2785-HFE	
Q349	8-729-119-78	TRANSISTOR 2SC2785-HFE	
Q350	8-729-119-78	TRANSISTOR 2SC2785-HFE	
Q351	8-729-119-78	TRANSISTOR 2SC2785-HFE	
Q352	8-729-177-32	TRANSISTOR 2SD773	
Q353	8-729-900-89	TRANSISTOR DTC144ES	
Q355	8-729-119-76	TRANSISTOR 2SA1175-HFE	
Q381	8-729-900-36	TRANSISTOR DTC124ES	
Q1351	8-729-900-61	TRANSISTOR DTA114ES	
Q1352	8-729-900-61	TRANSISTOR DTA114ES	
Q1353	8-729-900-61	TRANSISTOR DTA114ES	
Q1354	8-729-900-61	TRANSISTOR DTA114ES	
Q1360	8-729-177-32	TRANSISTOR 2SD773	
Q1361	8-729-119-76	TRANSISTOR 2SA1175-HFE	
Q1363	8-729-119-78	TRANSISTOR 2SC2785-HFE	
<RESISTOR>			
R301	1-249-411-11	CARBON 330 5% 1/4W	
R302	1-249-411-11	CARBON 330 5% 1/4W	
R303	1-249-411-11	CARBON 330 5% 1/4W	
R304	1-249-409-11	CARBON 220 5% 1/4W	
R305	1-249-421-11	CARBON 2.2K 5% 1/4W	
R306	1-249-433-11	CARBON 22K 5% 1/4W	
R307	1-249-441-11	CARBON 100K 5% 1/4W	
R308	1-249-414-11	CARBON 560 5% 1/4W	
R309	1-249-405-11	CARBON 100 5% 1/4W	
R310	1-249-405-11	CARBON 100 5% 1/4W	
R311	1-249-405-11	CARBON 100 5% 1/4W	
R312	1-249-409-11	CARBON 220 5% 1/4W	
R313	1-249-437-11	CARBON 47K 5% 1/4W	
R314	1-249-413-11	CARBON 470 5% 1/4W	
R315	1-249-407-11	CARBON 150 5% 1/4W	
R316	1-249-407-11	CARBON 150 5% 1/4W	
R317	1-249-407-11	CARBON 150 5% 1/4W	
R318	1-249-433-11	CARBON 22K 5% 1/4W	
R319	1-249-409-11	CARBON 220 5% 1/4W	
R321	1-249-421-11	CARBON 2.2K 5% 1/4W	
R322	1-249-420-11	CARBON 1.8K 5% 1/4W	
R323	1-249-421-11	CARBON 2.2K 5% 1/4W	
R325	1-247-903-00	CARBON 1H 5% 1/4W	
R326	1-249-419-11	CARBON 1.5K 5% 1/4W	
R327	1-249-428-11	CARBON 8.2K 5% 1/4W	
R328	1-249-409-11	CARBON 220 5% 1/4W	
R329	1-249-409-11	CARBON 220 5% 1/4W	
R330	1-249-409-11	CARBON 220 5% 1/4W	
R331	1-249-418-11	CARBON 1.2K 5% 1/4W	
R332	1-249-401-11	CARBON 47 5% 1/4W	
R333	1-249-412-11	CARBON 390 5% 1/4W	
R334	1-249-408-11	CARBON 180 5% 1/4W	
R335	1-249-415-11	CARBON 680 5% 1/4W	
R336	1-249-418-11	CARBON 1.2K 5% 1/4W	
R337	1-214-746-00	METAL 5.1K 1% 1/4W	
R338	1-249-429-11	CARBON 10K 5% 1/4W	
R339	1-249-423-11	CARBON 3.3K 5% 1/4W	
R340	1-249-435-11	CARBON 33K 5% 1/4W	
R341	1-249-428-11	CARBON 8.2K 5% 1/4W	
R342	1-249-429-11	CARBON 10K 5% 1/4W	
R343	1-249-429-11	CARBON 10K 5% 1/4W	
R344	1-249-417-11	CARBON 1K 5% 1/4W	
R345	1-247-887-00	CARBON 220K 5% 1/4W	

REF. NO.	PART NO.	DESCRIPTION	REMARK
R346	1-249-429-11	CARBON 10K 5% 1/4W	
R347	1-249-429-11	CARBON 10K 5% 1/4W	
R348	1-249-437-11	CARBON 47K 5% 1/4W	
R349	1-249-410-11	CARBON 270 5% 1/4W	
R350	1-249-437-11	CARBON 47K 5% 1/4W	
R351	1-247-700-11	CARBON 100 5% 1/4W	
R352	1-249-437-11	CARBON 47K 5% 1/4W	
R353	1-247-881-00	CARBON 120K 5% 1/4W	
R354	1-249-427-11	CARBON 6.8K 5% 1/4W	
R355	1-249-423-11	CARBON 3.3K 5% 1/4W	
R356	1-249-427-11	CARBON 6.8K 5% 1/4W	
R357	1-249-409-11	CARBON 220 5% 1/4W	
R358	1-249-409-11	CARBON 220 5% 1/4W	
R359	1-249-418-11	CARBON 1.2K 5% 1/4W	
R360	1-249-410-11	CARBON 270 5% 1/4W	
R361	1-249-417-11	CARBON 1K 5% 1/4W	
R362	1-249-441-11	CARBON 100K 5% 1/4W	
R363	1-249-410-11	CARBON 270 5% 1/4W	
R364	1-249-417-11	CARBON 1K 5% 1/4W	
R365	1-249-409-11	CARBON 220 5% 1/4W	
R366	1-249-419-11	CARBON 1.5K 5% 1/4W	
R367	1-249-409-11	CARBON 220 5% 1/4W	
R368	1-249-436-11	CARBON 39K 5% 1/4W	
R369	1-249-425-11	CARBON 4.7K 5% 1/4W	
R370	1-249-417-11	CARBON 1K 5% 1/4W	
R371	1-249-418-11	CARBON 1.2K 5% 1/4W	
R373	1-249-428-11	CARBON 8.2K 5% 1/4W	
R374	1-249-431-11	CARBON 15K 5% 1/4W	
R377	1-249-436-11	CARBON 39K 5% 1/4W	
R378	1-249-441-11	CARBON 100K 5% 1/4W	
R379	1-249-435-11	CARBON 33K 5% 1/4W	
R380	1-249-436-11	CARBON 39K 5% 1/4W	
R381	1-249-417-11	CARBON 1K 5% 1/4W	
R382	1-249-409-11	CARBON 220 5% 1/4W	
R384	1-249-421-11	CARBON 2.2K 5% 1/4W	
R385	1-247-891-00	CARBON 330K 5% 1/4W	
R386	1-247-891-00	CARBON 330K 5% 1/4W	
R387	1-215-867-00	METAL OXIDE 470 5% 1W F	
R388	1-249-434-11	CARBON 27K 5% 1/4W	
R390	1-249-429-11	CARBON 10K 5% 1/4W	
R392	1-249-414-11	CARBON 560 5% 1/4W	
R393	1-249-414-11	CARBON 560 5% 1/4W	
R394	1-249-414-11	CARBON 560 5% 1/4W	
R395	1-249-417-11	CARBON 1K 5% 1/4W	
R396	1-249-410-11	CARBON 270 5% 1/4W	
R397	1-249-417-11	CARBON 1K 5% 1/4W	
R398	1-249-425-11	CARBON 4.7K 5% 1/4W	
R399	1-249-437-11	CARBON 47K 5% 1/4W	
R414	1-249-415-11	CARBON 680 5% 1/4W	
R415	1-249-416-11	CARBON 820 5% 1/4W	
R416	1-249-415-11	CARBON 680 5% 1/4W	
R417	1-249-415-11	CARBON 680 5% 1/4W	
R418	1-215-412-00	METAL 430 1% 1/6W	
R419	1-249-414-11	CARBON 560 5% 1/4W	
R420	1-249-414-11	CARBON 560 5% 1/4W	
R421	1-249-414-11	CARBON 560 5% 1/4W	
R425	1-249-409-11	CARBON 220 5% 1/4W	
R427	1-249-415-11	CARBON 680 5% 1/4W	
R428	1-249-409-11	CARBON 220 5% 1/4W	
R429	1-249-433-11	CARBON 22K 5% 1/4W	
R430	1-249-417-11	CARBON 1K 5% 1/4W	
R431	1-249-419-11	CARBON 1.5K 5% 1/4W	
R432	1-249-417-11	CARBON 1K 5% 1/4W	

B F

The components identified by
shading and mark Δ are critical
for safety.
Replace only with part number
specified.

REF. NO.	PART NO.	DESCRIPTION	REMARK	REF. NO.	PART NO.	DESCRIPTION	REMARK
R433	1-249-421-11	CARBON 2.2K 5% 1/4W		C605	Δ 1-161-964-61	CERAMIC 0.0047MF 250V	
R434	1-249-417-11	CARBON 1K 5% 1/4W		C606	Δ 1-161-964-61	CERAMIC 0.0047MF 250V	
R435	1-247-893-11	CARBON 390K 5% 1/4W		C607	Δ 1-161-964-61	CERAMIC 0.0047MF 250V	
R438	1-249-416-11	CARBON 820 5% 1/4W		C608	Δ 1-136-360-51	FILM 0.22MF 20% 250V	
R439	1-249-413-11	CARBON 470 5% 1/4W		C609	1-124-122-11	ELECT 100MF 20% 50V	
R440	1-249-435-11	CARBON 33K 5% 1/4W		C610	1-124-910-11	ELECT 47MF 20% 50V	
R441	1-249-435-11	CARBON 33K 5% 1/4W		C611	1-124-122-11	ELECT 100MF 20% 50V	
R444	1-249-417-11	CARBON 1K 5% 1/4W		C612	1-162-116-00	CERAMIC 680PF 10% 2KV	
R445	1-249-413-11	CARBON 470 5% 1/4W		C613	1-106-379-12	MYLAR 0.033MF 10% 200V	
R446	1-249-425-11	CARBON 4.7K 5% 1/4W		C618	1-125-555-11	ELECT 330MF 20% 400V	
R447	1-249-424-11	CARBON 3.9K 5% 1/4W		C620	1-129-724-00	FILM 0.068MF 20% 630V	
R448	1-249-429-11	CARBON 10K 5% 1/4W		C623	1-102-030-00	CERAMIC 330PF 10% 500V	
R449	1-249-423-11	CARBON 3.3K 5% 1/4W		C651	Δ 1-162-578-51	CERAMIC 0.0047MF 20% 400V	
R450	1-249-425-11	CARBON 4.7K 5% 1/4W		C652	Δ 1-162-578-51	CERAMIC 0.0047MF 20% 400V	
R452	1-249-429-11	CARBON 10K 5% 1/4W		C653	1-125-469-11	ELECT (BLOCK) 820MF 20% 200V	
R453	1-249-432-11	CARBON 18K 5% 1/4W		C654	1-124-607-11	ELECT 2200MF 20% 50V	
R454	1-249-437-11	CARBON 47K 5% 1/4W		C655	1-124-618-11	ELECT 2200MF 20% 35V	
R1308	1-249-413-11	CARBON 470 5% 1/4W		C656	1-124-360-00	ELECT 1000MF 20% 16V	
R1313	1-249-429-11	CARBON 10K 5% 1/4W		C658	1-102-030-00	CERAMIC 330PF 10% 500V	
R1315	1-249-429-11	CARBON 10K 5% 1/4W		C661	1-102-030-00	CERAMIC 330PF 10% 500V	
R2446	1-249-416-11	CARBON 820 5% 1/4W		C662	1-124-618-11	ELECT 2200MF 20% 35V	
R2447	1-249-416-11	CARBON 820 5% 1/4W		C663	1-136-173-00	FILM 0.47MF 5% 50V	
R2448	1-249-416-11	CARBON 820 5% 1/4W		C664	1-162-115-00	CERAMIC 330PF 10% 2KV	
R2449	1-249-416-11	CARBON 820 5% 1/4W		C690	Δ 1-162-578-51	CERAMIC 0.0047MF 20% 400V	
R2450	1-249-436-11	CARBON 39K 5% 1/4W		C691	Δ 1-162-578-51	CERAMIC 0.0047MF 20% 400V	
R2451	1-249-435-11	CARBON 33K 5% 1/4W		<CONNECTOR>			
R2460	1-249-424-11	CARBON 3.9K 5% 1/4W		CNF1	*1-506-348-99	PIN, CONNECTOR 3P	
R2461	1-249-432-11	CARBON 18K 5% 1/4W		CNF2	*1-508-765-00	PIN, CONNECTOR (5MM PITCH) 3P	
R2462	1-249-425-11	CARBON 4.7K 5% 1/4W		CNF3	*1-508-786-00	PIN, CONNECTOR (5MM PITCH) 2P	
R2463	1-249-419-11	CARBON 1.5K 5% 1/4W		CNF4	*1-564-513-11	PLUG, CONNECTOR 10P	
R2465	1-249-417-11	CARBON 1K 5% 1/4W		CNF5	*1-564-104-00	PIN, CONNECTOR 3P	
R2466	1-249-417-11	CARBON 1K 5% 1/4W		CNF6	*1-508-767-00	PIN, CONNECTOR (5MM PITCH) 5P	
R2472	1-249-401-11	CARBON 47 5% 1/4W		CNF8	*1-564-505-11	PLUG, CONNECTOR 2P	
<VARIABLE RESISTOR>				<DIODE>			
RV301	1-228-993-00	RES, ADJ, CARBON 4.7K		D601	Δ 8-719-946-90	DIODE KB4JL-6088	
RV331	1-230-504-11	RES, ADJ, CARBON 220		D605	8-719-302-21	DIODE EU2Z	
<SWITCH>				D607	8-719-300-70	DIODE RH-1C	
S301	1-554-186-00	SWITCH, LEVER		D610	8-719-302-21	DIODE EU2Z	
<TRANSFORMER>				D651	8-719-939-07	DIODE ERD38-06	
T331	1-404-584-11	COIL		D652	8-719-301-64	DIODE RU-40S	
<CRYSTAL>				D653	8-719-300-59	DIODE CTU-12S	
X331	1-567-413-11	VIBRATOR, CRYSTAL		D654	8-719-300-33	DIODE RU-3AM	
X332	1-527-789-00	VIBRATOR, CRYSTAL		D655	8-719-300-33	DIODE RU-3AM	
<CAPACITOR>				D657	8-719-300-59	DIODE CTU-12S	
C601	1-130-711-00	FILM 0.22MF 20% 250V		<FUSE>			
C602	Δ 1-136-567-51	FILM 0.47MF 20% 250V		F601	Δ 1-532-299-11	FUSE, TIME LAG 5A/250V	
C603	Δ 1-161-964-61	CERAMIC 0.0047MF 20% 250V		*1-533-189-11	HOLDER, FUSE; F601		
*****				<IC>			
*A-1245-463-A	F BOARD, COMPLETE			IC602 8-749-920-63 IC STR-S5941			
*****				<COIL>			
*A-341-751-01	EYELET			L658	1-410-397-21	FERRITE BEAD INDUCTOR	
*A-341-752-01	EYELET (EY1,EY2,EY3,EY4,EY21,EY22)			L659	1-410-397-21	FERRITE BEAD INDUCTOR	
<CAPACITOR>				L660	1-410-397-21	FERRITE BEAD INDUCTOR	
C601	1-130-711-00	FILM 0.22MF 20% 250V		L661	1-410-397-21	FERRITE BEAD INDUCTOR	
C602	Δ 1-136-567-51	FILM 0.47MF 20% 250V		<RELAY>			
C603	Δ 1-161-964-61	CERAMIC 0.0047MF 20% 250V		<TRANSFORMER>			
<RELAY>				<THERMISTOR>			
<TRANSFORMER>				<DIODE>			
<THERMISTOR>				<CAPACITOR>			
<DIODE>				<RELAY>			
<CAPACITOR>				<TRANSFORMER>			
<RELAY>				<THERMISTOR>			
<TRANSFORMER>				<DIODE>			
<THERMISTOR>				<CAPACITOR>			
<DIODE>				<RELAY>			
<CAPACITOR>				<TRANSFORMER>			
<RELAY>				<THERMISTOR>			
<TRANSFORMER>				<DIODE>			
<THERMISTOR>				<CAPACITOR>			
<DIODE>				<RELAY>			
<CAPACITOR>				<TRANSFORMER>			
<RELAY>				<THERMISTOR>			
<TRANSFORMER>				<DIODE>			
<THERMISTOR>				<CAPACITOR>			
<DIODE>				<RELAY>			
<CAPACITOR>				<TRANSFORMER>			
<RELAY>				<THERMISTOR>			
<TRANSFORMER>				<DIODE>			
<THERMISTOR>				<CAPACITOR>			
<DIODE>				<RELAY>			
<CAPACITOR>				<TRANSFORMER>			
<RELAY>				<THERMISTOR>			
<TRANSFORMER>				<DIODE>			
<THERMISTOR>				<CAPACITOR>			
<DIODE>				<RELAY>			
<CAPACITOR>				<TRANSFORMER>			
<RELAY>				<THERMISTOR>			
<TRANSFORMER>				<DIODE>			
<THERMISTOR>				<CAPACITOR>			
<DIODE>				<RELAY>			
<CAPACITOR>				<TRANSFORMER>			
<RELAY>				<THERMISTOR>			
<TRANSFORMER>				<DIODE>			
<THERMISTOR>				<CAPACITOR>			
<DIODE>				<RELAY>			
<CAPACITOR>				<TRANSFORMER>			
<RELAY>				<THERMISTOR>			
<TRANSFORMER>				<DIODE>			
<THERMISTOR>				<CAPACITOR>			
<DIODE>				<RELAY>			
<CAPACITOR>				<TRANSFORMER>			
<RELAY>				<THERMISTOR>			
<TRANSFORMER>				<DIODE>			
<THERMISTOR>				<CAPACITOR>			
<DIODE>				<RELAY>			
<CAPACITOR>				<TRANSFORMER>			
<RELAY>				<THERMISTOR>			
<TRANSFORMER>				<DIODE>			
<THERMISTOR>				<CAPACITOR>			
<DIODE>				<RELAY>			
<CAPACITOR>				<TRANSFORMER>			
<RELAY>				<THERMISTOR>			
<TRANSFORMER>				<DIODE>			
<THERMISTOR>				<CAPACITOR>			
<DIODE>				<RELAY>			
<CAPACITOR>				<TRANSFORMER>			
<RELAY>				<THERMISTOR>			
<TRANSFORMER>				<DIODE>			
<THERMISTOR>				<CAPACITOR>			
<DIODE>				<RELAY>			
<CAPACITOR>				<TRANSFORMER>			
<RELAY>				<THERMISTOR>			
<TRANSFORMER>				<DIODE>			
<THERMISTOR>				<CAPACITOR>			
<DIODE>				<RELAY>			
<CAPACITOR>				<TRANSFORMER>			
<RELAY>				<THERMISTOR>			
<TRANSFORMER>				<DIODE>			
<THERMISTOR>				<CAPACITOR>			
<DIODE>				<RELAY>			
<CAPACITOR>				<TRANSFORMER>			
<RELAY>				<THERMISTOR>			
<TRANSFORMER>				<DIODE>			
<THERMISTOR>				<CAPACITOR>			
<DIODE>				<RELAY>			
<CAPACITOR>				<TRANSFORMER>			
<RELAY>				<THERMISTOR>			
<TRANSFORMER>				<DIODE>			
<THERMISTOR>				<CAPACITOR>			
<DIODE>				<RELAY>			
<CAPACITOR>				<TRANSFORMER>			
<RELAY>				<THERMISTOR>			
<TRANSFORMER>				<DIODE>			
<THERMISTOR>				<CAPACITOR>			
<DIODE>				<RELAY>			
<CAPACITOR>				<TRANSFORMER>			
<RELAY>				<THERMISTOR>			
<TRANSFORMER>				<DIODE>			
<THERMISTOR>				<CAPACITOR>			
<DIODE>				<RELAY>			
<CAPACITOR>				<TRANSFORMER>			
<RELAY>				<THERMISTOR>			
<TRANSFORMER>				<DIODE>			
<THERMISTOR>				<CAPACITOR>			
<DIODE>				<RELAY>			
<CAPACITOR>				<TRANSFORMER>			
<RELAY>				<THERMISTOR>			
<TRANSFORMER>				<DIODE>			
<THERMISTOR>				<CAPACITOR>			
<DIODE>				<RELAY>			
<CAPACITOR>				<TRANSFORMER>			
<RELAY>				<THERMISTOR>			
<TRANSFORMER>				<DIODE>			
<THERMISTOR>				<CAPACITOR>			
<DIODE>				<RELAY>			
<CAPACITOR>				<TRANSFORMER>			
<RELAY>				<THERMISTOR>			
<TRANSFORMER>				<DIODE>			
<THERMISTOR>				<CAPACITOR>			
<DIODE>				<RELAY>			
<CAPACITOR>				<TRANSFORMER>			
<RELAY>				<THERMISTOR>			
<TRANSFORMER>				<DIODE>			
<THERMISTOR>				<CAPACITOR>			
<DIODE>				<RELAY>			
<CAPACITOR>				<TRANSFORMER>			
<RELAY>				<THERMISTOR>			
<TRANSFORMER>				<DIODE>			
<THERMISTOR>				<CAPACITOR>			
<DIODE>				<RELAY>			
<CAPACITOR>				<TRANSFORMER>			
<RELAY>				<THERMISTOR>			
<TRANSFORMER>				<DIODE>			
<THERMISTOR>				<CAPACITOR>			
<DIODE>				<RELAY>			
<CAPACITOR>				<TRANSFORMER>			
<RELAY>				<THERMISTOR>			
<TRANSFORMER>				<DIODE>			
<THERMISTOR>				<CAPACITOR>			
<DIODE>				<RELAY>			
<CAPACITOR>				<TRANSFORMER>			
<RELAY>				<THERMISTOR>			
<TRANSFORMER>				<DIODE>			
<THERMISTOR>				<CAPACITOR>			
<DIODE>				<RELAY>			
<CAPACITOR>				<TRANSFORMER>			
<RELAY>				<THERMISTOR>			
<TRANSFORMER>				<DIODE>			
<THERMISTOR>				<CAPACITOR>			
<DIODE>				<RELAY>			
<CAPACITOR>				<TRANSFORMER>			
<RELAY>				<THERMISTOR>			
<TRANSFORMER>				<DIODE>			
<THERMISTOR>				<CAPACITOR>			
<DIODE>				<RELAY>			
<CAPACITOR>				<TRANSFORMER>			
<RELAY>				<THERMISTOR>			
<TRANSFORMER>				<DIODE>			
<THERMISTOR>				<CAPACITOR>			
<DIODE>				<RELAY>			
<CAPACITOR>				<TRANSFORMER>			
<RELAY>				<THERMISTOR>			
<TRANSFORMER>				<DIODE>			
<THERMISTOR>				<CAPACITOR>			
<DIODE>				<RELAY>			
<CAPACITOR>				<TRANSFORMER>			
<RELAY>				<THERMISTOR>			
<TRANSFORMER>				<DIODE>			
<THERMISTOR>				<CAPACITOR>			
<DIODE>				<RELAY>			
<CAPACITOR>				<TRANSFORMER>			
<RELAY>				<THERMISTOR>			
<TRANSFORMER>				<DIODE>			
<THERMISTOR>				<CAPACITOR>			
<DIODE>				<RELAY>			
<CAPACITOR>				<TRANSFORMER>			
<RELAY>				<THERMISTOR>			
<TRANSFORMER>				<DIODE>			
<THERMISTOR>				<CAPACITOR>			
<DIODE>				<RELAY>			
<CAPACITOR>				<TRANSFORMER>			
<RELAY>				<THERMISTOR>			
<TRANSFORMER>				<DIODE>			
<THERMISTOR>				<CAPACITOR>			
<DIODE>				<RELAY>			
<CAPACITOR>				<TRANSFORMER>			
<RELAY>				<THERMISTOR>			
<TRANSFORMER>				<DIODE>			
<THERMISTOR>				<CAPACITOR>			
<DIODE>				<RELAY>			
<CAPACITOR>				<TRANSFORMER>			
<RELAY>				<THERMISTOR>			
<TRANSFORMER>				<DIODE>			
<THERMISTOR>				<CAPACITOR>			
<DIODE>				<RELAY>			
<CAPACITOR>				<TRANSFORMER>			
<RELAY>				<THERMISTOR>			
<TRANSFORMER>				<DIODE>			
<THERMISTOR>				<CAPACITOR>			
<DIODE>				<RELAY>			
<CAPACITOR>				<TRANSFORMER>			
<RELAY>				<THERMISTOR>			
<TRANSFORMER>				<DIODE>			
<THERMISTOR>				<CAPACITOR>			
<DIODE>				<RELAY>			
<CAPACITOR>				<TRANSFORMER>			
<RELAY>				<THERMISTOR>			
<TRANSFORMER>				<DIODE>			
<THERMISTOR>				<CAPACITOR>			
<DIODE>				<RELAY>			
<CAPACITOR>				<TRANSFORMER>			
<RELAY>				<THERMISTOR>			
<TRANSFORMER>				<DIODE>			
<THERMISTOR>				<CAPACITOR>			
<DIODE>				<RELAY>			
<CAPACITOR>				<TRANSFORMER>			
<RELAY>				<THERMISTOR>			
<TRANSFORMER>				<DIODE>			
<THERMISTOR>				<CAPACITOR>			
<DIODE>				<RELAY>			
<CAPACITOR>				<TRANSFORMER>			
<RELAY>				<THERMISTOR>			
<TRANSFORMER>				<DIODE>			
<THERMISTOR>				<CAPACITOR>			
<DIODE>				<RELAY>			
<CAPACITOR>				<TRANSFORMER>			
<RELAY>				<THERMISTOR>			
<TRANSFORMER>				<DIODE>			
<THERMISTOR>				<CAPACITOR>			
<DIODE>				<RELAY>			
<CAPACITOR>				<TRANSFORMER>			
<RELAY>				<THERMISTOR>			
<TRANSFORMER>				<DIODE>			
<THERM							

F A

The components identified by
shading and mark Δ are critical
for safety.
Replace only with part number
specified.

REF. NO.	PART NO.	DESCRIPTION	REMARK	REF. NO.	PART NO.	DESCRIPTION	REMARK
L662	1-410-397-21	FERRITE BEAD INDUCTOR		C110	1-101-003-00	CERAMIC 0.0047MF 50V	
<IC LINK>				C111	1-124-477-11	ELECT 47MF 20% 16V	
PS652A	1-532-984-91	LINK, IC 2A		C112	1-101-003-00	CERAMIC 0.0047MF 50V	
PS653A	1-532-984-91	LINK, IC 2A		C113	1-101-004-00	CERAMIC 0.01MF 50V	
PS654A	1-532-984-91	LINK, IC 2A		C115	1-123-875-11	ELECT 10MF 20% 50V	
				C116	1-123-875-11	ELECT 10MF 20% 50V	
<TRANSISTOR>				C117	1-123-875-11	ELECT 10MF 20% 50V	
Q651	8-729-900-36	TRANSISTOR DTC124ES		C118	1-123-875-11	ELECT 10MF 20% 50V	
Q652	8-729-177-32	TRANSISTOR 2SD773		C119	1-136-161-00	MYLAR 0.047MF 10% 50V	
				C120	1-102-965-00	CERAMIC 39PF 5% 50V	
				C121	1-124-477-11	ELECT 47MF 20% 16V	
<RESISTOR>				C122	1-124-477-11	ELECT 47MF 20% 16V	
R601	1-216-400-11	METAL OXIDE 8.2 5% 3W F		C123	1-101-004-00	CERAMIC 0.01MF 50V	
R602	1-247-895-00	CARBON 470K 5% 1/4W		C124	1-124-477-11	ELECT 47MF 20% 16V	
R603	1-216-400-11	METAL OXIDE 8.2 5% 3W F		C127	1-124-477-11	ELECT 47MF 20% 16V	
R604	1-207-612-00	WIREWOUND 0.1 10% 2W F		C128	1-124-477-11	ELECT 47MF 20% 16V	
R605	1-205-949-11	WIREWOUND 1.8 5% 10W		C129	1-124-477-11	ELECT 47MF 20% 16V	
R606	1-205-949-11	WIREWOUND 1.8 5% 10W		C130	1-126-101-11	ELECT 100MF 20% 16V	
R607	1-215-883-11	METAL OXIDE 33 5% 2W F		C132	1-101-888-00	CERAMIC 68PF 5% 50V	
R608	1-216-400-11	METAL OXIDE 8.2 5% 3W F		C133	1-102-973-00	CERAMIC 100PF 5% 50V	
R609	1-216-400-11	METAL OXIDE 8.2 5% 3W F		C134	1-102-963-00	CERAMIC 33PF 5% 50V	
R611	1-216-398-11	METAL OXIDE 5.6 5% 3W F		C135	1-124-477-11	ELECT 47MF 20% 16V	
R612	1-216-489-11	METAL OXIDE 27K 5% 3W F		C136	1-124-477-11	ELECT 47MF 20% 16V	
R613	1-216-489-11	METAL OXIDE 27K 5% 3W F		C137	1-124-477-11	ELECT 47MF 20% 16V	
R651A	1-247-289-11	CARBON 8.2K 5% 1/4W		C138	1-136-165-00	MYLAR 0.1MF 10% 50V	
R653	1-215-925-11	METAL OXIDE 22K 5% 3W F		C141	1-102-822-00	CERAMIC 390PF 5% 50V	
R654	1-249-425-11	CARBON 4.7K 5% 1/4W		C142	1-101-361-00	CERAMIC 150PF 5% 50V	
R655	1-247-739-11	CARBON 100 5% 1/2W		C143	1-102-973-00	CERAMIC 100PF 5% 50V	
				C145	1-101-888-00	CERAMIC 68PF 5% 50V	
				C146	1-102-965-00	CERAMIC 39PF 5% 50V	
				C149	1-102-114-00	CERAMIC 470PF 10% 50V	
<RELAY>				C150	1-102-114-00	CERAMIC 470PF 10% 50V	
RY601A	1-515-579-11	RELAY		C151	1-124-477-11	ELECT 47MF 20% 16V	
<TRANSFORMER>				C152	1-136-161-00	MYLAR 0.047MF 10% 50V	
T601	1-421-866-12	LFT		C153	1-101-004-00	CERAMIC 0.01MF 50V	
T602A	1-421-776-11	LFT		C154	1-101-004-00	CERAMIC 0.01MF 50V	
T603A	1-449-500-21	TRANSFORMER, REGULATOR		C155	1-124-477-11	ELECT 47MF 20% 16V	
T604A	1-421-776-11	LFT		C181	1-101-004-00	CERAMIC 0.01MF 50V	
<THERMISTOR>				<FILTER>			
THP601A	1-808-059-31	THERMISTOR, POSITIVE		CD101	1-404-684-11	DISCRIMINATOR, CERAMIC	
<CAPACITOR>				CF101	1-567-569-11	FILTER, CERAMIC	
<CONNECTOR>				<DIODE>			
*A-1296-678-A	A BOARD, COMPLETE			CNA11	*1-566-659-11	CONNECTOR, HINGE (SOCKET) 18P	
	*****			CNA16	*1-560-290-00	PLUG, CONNECTOR (2.5MM PITCH)	
	1-464-964-11 IF BLOCK (IFG-5.5S)			CNA17	*1-564-886-21	PLUG, CONNECTOR 9P	
				CNA18	*1-565-503-11	CONNECTOR, BOARD TO BOARD 12P	
<IC>				<DIODE>			
C101	1-126-233-11	ELECT 22MF 20% 50V		D101	8-719-000-12	DIODE MC931	
C102	1-126-103-11	ELECT 470NF 20% 16V		D108	8-719-911-19	DIODE 1SS119	
C103	1-130-475-00	MYLAR 0.0022MF 10% 50V		D109	8-719-911-19	DIODE 1SS119	
C104	1-124-477-11	ELECT 47MF 20% 16V					
C105	1-101-003-00	CERAMIC 0.0047MF 50V					
C106	1-126-233-11	ELECT 22MF 20% 50V					
C107	1-136-177-00	FILM 1MF 5% 50V					
C108	1-101-004-00	CERAMIC 0.01MF 50V					
C109	1-101-003-00	CERAMIC 0.0047MF 50V					

A C

REF. NO.	PART NO.	DESCRIPTION	REMARK	REF. NO.	PART NO.	DESCRIPTION	REMARK
<COIL>				R144	1-249-417-11	CARBON 1K 5% 1/4W	
L100	1-410-116-11	INDUCTOR 560UH		R145	1-249-413-11	CARBON 470 5% 1/4W	
L101	1-408-225-00	INDUCTOR 3.3UH		R146	1-249-421-11	CARBON 2.2K 5% 1/4W	
L102	1-410-470-11	INDUCTOR 10UH		R147	1-249-429-11	CARBON 10K 5% 1/4W	
L103	1-408-408-00	INDUCTOR 8.2UH		R148	1-249-415-11	CARBON 680 5% 1/4W	
L104	1-410-476-11	INDUCTOR 33UH		R152	1-249-417-11	CARBON 1K 5% 1/4W	
L106	1-410-471-11	INDUCTOR 12UH		R153	1-249-417-11	CARBON 1K 5% 1/4W	
L108	1-410-471-11	INDUCTOR 12UH		R154	1-247-710-11	CARBON 560 5% 1/4W	
L109	1-408-420-00	INDUCTOR 82UH		R155	1-249-417-11	CARBON 1K 5% 1/4W	
				R157	1-247-713-11	CARBON 1K 5% 1/4W	
<TRANSISTOR>				R158	1-247-704-11	CARBON 220 5% 1/4W	
Q106	8-729-900-65	TRANSISTOR DTA144BS		R159	1-247-704-11	CARBON 220 5% 1/4W	
Q107	8-729-900-89	TRANSISTOR DTC144BS		R160	1-249-396-11	CARBON 18 5% 1/4W	
Q109	8-729-901-59	TRANSISTOR 8F199		R164	1-247-696-11	CARBON 47 5% 1/4W	
Q110	8-729-119-78	TRANSISTOR 2SC2785-HFE		R165	1-247-696-11	CARBON 47 5% 1/4W	
Q111	8-729-119-78	TRANSISTOR 25C2785-HFE		R166	1-249-460-11	CARBON 15K 5% 1/4W	
Q112	8-729-119-78	TRANSISTOR 25C2785-HFE		R181	1-247-713-11	CARBON 1K 5% 1/4W	
Q113	8-729-119-78	TRANSISTOR 25C2785-HFE		R182	1-249-425-11	CARBON 4.7K 5% 1/4W	
Q114	8-729-119-78	TRANSISTOR 25C2785-HFE		<IF BLOCK>			
Q115	8-729-119-78	TRANSISTOR 25C2785-HFE		SIF101	1-464-963-11	IF BLOCK (1FG-334F)	
Q116	8-729-119-78	TRANSISTOR 25C2785-HFE		VIF101	1-464-962-11	IF BLOCK (1FG-389FS)	
Q118	8-729-119-76	TRANSISTOR 2SA1175-HFE		<TRANSFORMER>			
Q181	8-729-119-78	TRANSISTOR 25C2785-HFE		T101	1-404-806-11	COIL	
Q182	8-729-900-89	TRANSISTOR DTC144BS		T102	1-404-493-00	COIL	
<RESISTOR>				<TUNER>			
R102	1-249-429-11	CARBON 10K 5% 1/4W		TU101A	1-465-059-11	TUNER ET (UV-616S)	
R103	1-249-429-11	CARBON 10K 5% 1/4W		<CRYSTAL>			
R104	1-249-465-11	CARBON 47K 5% 1/4W		X101	1-527-726-00	VIBRATOR, CRYSTAL	
R105	1-247-721-11	CARBON 4.7K 5% 1/4W		*****			
R106	1-247-721-11	CARBON 4.7K 5% 1/4W		*A-1330-967-A	C BOARD, COMPLETE		
R107	1-249-432-11	CARBON 18K 5% 1/4W		*****			
R109	1-249-441-11	CARBON 100K 5% 1/4W		*4-379-160-01	COVER (REAR LID), CV		
R110	1-249-429-11	CARBON 10K 5% 1/4W		*4-379-167-01	COVER (MAIN), CV		
R111	1-249-423-11	CARBON 3.3K 5% 1/4W		<CAPACITOR>			
R112	1-249-425-11	CARBON 4.7K 5% 1/4W		C704	1-102-116-00	CERAMIC 680PF 10% 50V	
R113	1-249-425-11	CARBON 4.7K 5% 1/4W		C705	1-102-980-00	CERAMIC 270PF 5% 50V	
R114	1-249-413-11	CARBON 470 5% 1/4W		C706	1-102-116-00	CERAMIC 680PF 10% 50V	
R115	1-249-405-11	CARBON 100 5% 1/4W		C707	1-162-116-00	CERAMIC 680PF 10% 2KV	
R118	1-247-725-11	CARBON 10K 5% 1/4W		C708	1-162-114-00	CERAMIC 0.0047MF 2KV	
R121	1-249-429-11	CARBON 10K 5% 1/4W		C709	1-102-116-00	CERAMIC 680PF 10% 50V	
R122	1-249-428-11	CARBON 8.2K 5% 1/4W		C710	1-123-947-00	ELECT 20% 250V	
R123	1-249-460-11	CARBON 15K 5% 1/4W		C711	1-101-880-00	CERAMIC 47PF 5% 50V	
R124	1-249-460-11	CARBON 15K 5% 1/4W		C712	1-102-820-00	CERAMIC 330PF 5% 50V	
R125	1-249-460-11	CARBON 15K 5% 1/4W		C714	1-126-103-11	ELECT 20% 16V	
R126	1-249-460-11	CARBON 15K 5% 1/4W		C716	1-162-622-11	CERAMIC 330PF 10% 400V	
R127	1-249-460-11	CARBON 15K 5% 1/4W		C717	1-102-114-00	CERAMIC 470PF 10% 50V	
R128	1-247-708-11	CARBON 470 5% 1/4W		C718	1-102-114-00	CERAMIC 470PF 10% 50V	
R129	1-249-421-11	CARBON 2.2K 5% 1/4W		C719	1-102-114-00	CERAMIC 470PF 10% 50V	
R130	1-249-421-11	CARBON 2.2K 5% 1/4W		C721	1-123-875-11	ELECT 10MF 20% 50V	
R131	1-249-422-11	CARBON 2.7K 5% 1/4W		<CONNECTOR>			
R133	1-249-422-11	CARBON 2.7K 5% 1/4W		CNC71	1-506-348-99	PIN, CONNECTOR 3P	
R134	1-249-422-11	CARBON 2.7K 5% 1/4W		CNC72	1-564-509-11	PLUG, CONNECTOR 6P	
R136	1-249-413-11	CARBON 470 5% 1/4W		CNC81	1-564-506-11	PLUG, CONNECTOR 3P	
R137	1-249-405-11	CARBON 100 5% 1/4W		CNC82	1-508-765-00	PIN, CONNECTOR (5MM PITCH) 3P	
R138	1-249-413-11	CARBON 470 5% 1/4W		<DIODE>			
R139	1-249-413-11	CARBON 470 5% 1/4W		D701	8-719-911-19	DIODE 1SS119	
R140	1-249-418-11	CARBON 1.2K 5% 1/4W		D702	8-719-911-19	DIODE 1SS119	
R141	1-249-413-11	CARBON 470 5% 1/4W		D703	8-719-911-19	DIODE 1SS119	
R142	1-249-413-11	CARBON 470 5% 1/4W		D704	8-719-911-19	DIODE 1SS119	
R143	1-249-416-11	CARBON 820 5% 1/4W		D705	8-719-911-19	DIODE 1SS119	

The components identified by shading and mark Δ are critical for safety.
Replace only with part number specified.The components identified by shading and mark Δ are critical for safety.
Replace only with part number specified.

REF.NO.	PART NO.	DESCRIPTION	REMARK	REF.NO.	PART NO.	DESCRIPTION	REMARK
CNC71	=1-506-348-99	PIN, CONNECTOR 3P		R726	1-202-824-00	SOLID 3.3K 10% 1/2W	
CNC72	=1-564-509-11	PLUG, CONNECTOR 6P		R727	1-249-409-11	CARBON 220 5% 1/4W	
CNC81	=1-564-506-11	PLUG, CONNECTOR 3P		R728	1-216-350-11	METAL OXIDE 1.2 5% 1W F	
CNC82	=1-508-765-00	PIN, CONNECTOR (5MM PITCH) 3P		R729	1-249-416-11	CARBON 820 5% 1/4W	
<DIODE>				R731	1-249-423-11	CARBON 3.3K 5% 1/4W	
D701	8-719-911-19	DIODE 1SS119		R732	1-249-415-11	CARBON 680 5% 1/4W	
D702	8-719-911-19	DIODE 1SS119		R733	1-247-711-11	CARBON 680 5% 1/4W	
D703	8-719-911-19	DIODE 1SS119		R734	1-249-405-11	CARBON 100 5% 1/4W	
D704	8-719-911-19	DIODE 1SS119		R735	1-214-779-00	METAL 120K 1% 1/4W	
D705	8-719-911-19	DIODE 1SS119		R736	1-216-486-00	METAL OXIDE 8.2K 5% 3W F	
D706	8-719-911-19	DIODE 1SS119		R737	1-214-777-00	METAL 100K 1% 1/4W	
D707	8-719-911-19	DIODE 1SS119		R738	1-202-549-00	SOLID 100 10% 1/2W	
D708	8-719-911-19	DIODE 1SS119		R739	1-249-417-11	CARBON 1K 5% 1/4W	
D709	8-719-911-19	DIODE 1SS119		R740	1-202-846-00	SOLID 470K 10% 1/2W	
D710	8-719-911-19	DIODE 1SS119		R741	1-202-837-00	SOLID 82K 10% 1/2W	
<VARIABLE RESISTOR>				*****			
D711	8-719-300-33	DIODE RU-3AM		RV701	1-230-641-11	RES, ADJ. METAL GLAZE 2.2M	
D713	8-719-110-14	DIODE RD9.1BS-33		RV702	1-230-619-11	RES, ADJ. METAL GLAZE 110M	
<JACK>				RV703	1-228-991-00	RES, ADJ. CARBON 2.2K	
J701	1-526-798-51	SOCKET, PICTURE TUBE		RV704	1-228-991-00	RES, ADJ. CARBON 2.2K	
<COIL>				*****			
L704	1-410-476-11	INDUCTOR 33UH		*A-1342-088-A	VM BOARD, COMPLETE		
<TRANSISTOR>				*****			
Q702	8-729-119-78	TRANSISTOR 2SC2785-HFE		*1-564-506-11	PLUG, CONNECTOR 3P		
Q703	8-729-326-11	TRANSISTOR 2SC2611		*1-564-507-11	PLUG, CONNECTOR 4P		
Q704	8-729-200-17	TRANSISTOR 2SA1091		<CAPACITOR>			
Q705	8-729-119-78	TRANSISTOR 2SC2785-HFE		C751	1-102-971-00	CERAMIC 82PF 5% 50V	
Q706	8-729-326-11	TRANSISTOR 2SC2611		C752	1-106-349-00	MYLAR 0.0018MF 10% 100V	
Q707	8-729-200-17	TRANSISTOR 2SA1091		C754	1-126-101-11	ELECT 100MF 20% 16V	
Q708	8-729-119-78	TRANSISTOR 2SC2785-HFE		C755	1-102-973-00	CERAMIC 100PF 5% 50V	
Q709	8-729-326-11	TRANSISTOR 2SC2611		C756	1-106-367-00	MYLAR 0.01MF 10% 100V	
Q710	8-729-200-17	TRANSISTOR 2SA1091		C758	1-106-367-00	MYLAR 0.01MF 10% 100V	
<RESISTOR>				C760	1-124-925-11	ELECT 2.2MF 20% 50V	
R703	1-102-822-00	CERAMIC 390PF 5% 50V		C761	1-106-220-00	MYLAR 0.1MF 10% 100V	
R704	1-216-486-00	METAL OXIDE 8.2K 5% 3W F		C763	1-124-122-11	ELECT 100MF 20% 35V	
R705	1-202-824-00	SOLID 3.3K 10% 1/2W		C764	1-126-176-11	ELECT 220MF 20% 6.3V	
R706	1-249-409-11	CARBON 220 5% 1/4W		C765	1-101-006-00	CERAMIC 0.047MF 50V	
R707	1-247-706-11	CARBON 330 5% 1/4W		C766	1-124-122-11	ELECT 100MF 20% 35V	
R708	1-247-692-11	CARBON 22 5% 1/4W		<COIL>			
R709	1-202-844-00	SOLID 330K 10% 1/2W		L751	1-408-413-00	INDUCTOR 22UH	
R710	1-215-453-00	METAL 22K 1% 1/6W		L752	1-410-482-31	INDUCTOR 100UH	
R712	1-249-417-11	CARBON 1K 5% 1/4W		<TRANSISTOR>			
R713	1-215-461-00	METAL 47K 1% 1/6W		Q751	8-729-119-78	TRANSISTOR 2SC2785-HFE	
R714	1-216-486-00	METAL OXIDE 8.2K 5% 3W F		Q752	8-729-119-78	TRANSISTOR 2SC2785-HFE	
R715	1-202-824-00	SOLID 3.3K 10% 1/2W		Q753	8-729-140-96	TRANSISTOR 2SD774-34	
R716	1-247-704-11	CARBON 220 5% 1/4W		Q754	8-729-177-22	TRANSISTOR 2SB772-Q	
R717	1-247-711-11	CARBON 680 5% 1/4W		Q755	8-729-188-23	TRANSISTOR 2SD882-P	
R718	1-202-814-11	SOLID 33K 10% 1/2W		Q756	8-729-808-76	TRANSISTOR 2SD1913SA	
R720	1-249-423-11	CARBON 3.3K 5% 1/4W		Q757	8-729-119-78	TRANSISTOR 2SC2785-HFE	
R721	1-202-842-11	SOLID 220K 10% 1/2W		<RESISTOR>			
R722	1-202-848-00	SOLID 680K 10% 1/2W		R751	1-249-409-11	CARBON 220 5% 1/4W	
R723	1-249-417-11	CARBON 1K 5% 1/4W		R752	1-249-409-11	CARBON 220 5% 1/4W	
R724	1-202-846-00	SOLID 470K 10% 1/2W					
R725	1-202-838-00	SOLID 100K 10% 1/2W					

C VM

VM D

The components identified by shading and mark Δ are critical for safety.
Replace only with part number specified.

REF. NO.	PART NO.	DESCRIPTION	REMARK	REF. NO.	PART NO.	DESCRIPTION	REMARK
R753	1-249-418-11	CARBON 1.2K 5% 1/4W		C541	1-124-902-00	ELECT 0.47MF 20% 50V	
R754	1-249-416-11	CARBON 820 5% 1/4W		C591	1-123-875-11	ELECT 10MF 20% 50V	
R755	1-216-431-11	METAL OXIDE 560 5% 1W	F	C592	1-124-910-11	ELECT 47MF 20% 50V	
R756	1-249-414-11	CARBON 560 5% 1/4W		C593	1-102-820-00	CERAMIC 330PF 5% 50V	
R757	1-249-426-11	CARBON 5.6K 5% 1/4W		C596	1-106-220-00	MYLAR 0.1MF 10% 100V	
R758	1-249-435-11	CARBON 33K 5% 1/4W		C597	1-102-951-00	CERAMIC 15PF 10% 50V	
R759	1-249-405-11	CARBON 100 5% 1/4W	F	C801	1-126-105-11	ELECT 1000MF 20% 35V	
R760	1-216-449-11	METAL OXIDE 56 5% 2W	F	C802	1-102-228-00	CERAMIC 470PF 10% 500V	
R764	1-249-409-11	CARBON 220 5% 1/4W		C804	1-123-948-00	ELECT 22MF 20% 250V	
R765	1-249-381-11	CARBON 1 5% 1/4W	F	C805	1-162-114-00	CERAMIC 0.0047MF 2KV	
R766	1-249-426-11	CARBON 5.6K 5% 1/4W		C806	1-106-387-00	MYLAR 0.068MF 10% 200V	
R767	1-249-417-11	CARBON 1K 5% 1/4W		C807	1-106-395-00	MYLAR 0.15MF 10% 200V	
R768	1-249-426-11	CARBON 5.6K 5% 1/4W		C810	1-124-494-00	ELECT 33MF 160V	
R769	1-249-409-11	CARBON 220 5% 1/4W		C811	1-136-541-11	FILM 1.5MF 5% 200V	
R771	1-249-423-11	CARBON 3.3K 5% 1/4W		C812	1-123-946-00	ELECT 4.7MF 20% 250V	
R772	1-249-391-11	CARBON 6.8 5% 1/4W	F	C813	1-102-212-00	CERAMIC 820PF 10% 500V	
R773	1-249-396-11	CARBON 18 5% 1/4W		C814 Δ	1-161-731-11	CERAMIC 0.001MF 10% 2KV	
R776	1-249-381-11	CARBON 1 5% 1/4W	F	C815	1-136-597-11	FILM 0.89MF 5% 200V	
*****				C817	1-136-686-11	FILM 0.018MF 3% 1.4KV	
*A-1345-857-A D. BOARD, COMPLETE				C818	1-136-759-11	FILM 0.039MF 5% 630V	
*****				C819 Δ	1-162-116-51	CERAMIC 680PF 10% 2KV	
*1-559-991-41 CONNECTOR ASSY 1P				C820	1-106-357-00	MYLAR 0.0039MF 200V	
*4-341-751-01 EYELET (EY5, EY6, EY8, EY9, EY10, EY14, EY15, EY16, EY17, EY26, EY27, EY28, EY29, EY30)				C820A	1-108-416-12	MYLAR 0.0039MF 200V	
*4-341-752-01 EYELET (EY1, EY2, EY3, EY4, EY12, EY13, EY20, EY21, EY23, EY24)				C821 Δ	1-162-116-51	CERAMIC 680PF 10% 2KV	
<CAPACITOR>				C822	1-102-114-00	CERAMIC 470PF 10% 50V	
C501	1-124-927-11	ELECT 4.7MF 20% 50V		C823	1-106-359-00	MYLAR 0.0047MF 10% 200V	
C502	1-124-927-11	ELECT 4.7MF 20% 50V		C824	1-102-212-00	CERAMIC 820PF 10% 500V	
C503	1-106-371-00	MYLAR 0.015MF 10% 100V		C828	1-106-383-00	MYLAR 0.047MF 10% 100V	
C504	1-101-361-00	CERAMIC 150PF 5% 50V		C829	1-106-379-12	MYLAR 0.035MF 10% 200V	
C505	1-130-473-00	MYLAR 0.0015MF 5% 50V		C849	1-102-112-00	CERAMIC 330PF 10% 50V	
C506	1-106-375-12	MYLAR 0.022MF 200V		C850	1-101-821-00	CERAMIC 0.0022MF 500V	
C507	1-136-171-00	FILM 0.33MF 5% 50V		C851	1-126-105-11	ELECT 1000MF 20% 35V	
C508	1-106-375-12	MYLAR 0.022MF 200V		C852	1-102-002-00	CERAMIC 680PF 10% 500V	
C509	1-106-220-00	MYLAR 0.1MF 10% 100V		C854	1-124-122-11	ELECT 100MF 20% 50V	
C510	1-161-959-00	CERAMIC 22PF 10% 500V		C855	1-124-499-11	ELECT 1MF 20% 50V	
C511	1-106-355-12	MYLAR 0.0033MF 10% 100V		C860	1-106-399-00	MYLAR 0.22MF 10% 200V	
C513	1-106-343-00	MYLAR 0.001MF 10% 100V		C861 Δ	1-161-731-11	CERAMIC 0.001MF 10% 2KV	
C514	1-106-228-00	MYLAR 0.22MF 10% 100V		C1501	1-124-925-11	ELECT 2.2MF 20% 50V	
C515	1-124-499-11	ELECT 1MF 20% 50V		C1502	1-123-875-11	ELECT 10MF 20% 50V	
C516	1-102-112-00	CERAMIC 330PF 10% 50V		C1503	1-106-343-00	MYLAR 0.001MF 10% 100V	
C517	1-124-910-11	ELECT 47MF 20% 50V		C1504	1-124-910-11	ELECT 47MF 20% 50V	
C518	1-124-902-00	ELECT 0.47MF 20% 50V		C1505	1-106-383-00	MYLAR 0.047MF 10% 100V	
C519	1-136-173-00	FILM 0.47MF 5% 50V		C1507	1-106-355-12	MYLAR 0.0033MF 10% 100V	
C520	1-102-121-00	CERAMIC 0.0022MF 10% 50V		C1508	1-123-875-11	ELECT 10MF 20% 50V	
C521	1-106-220-00	MYLAR 0.1MF 10% 100V		C1509	1-124-499-11	ELECT 1MF 20% 50V	
C522	1-126-105-11	ELECT 1000MF 20% 35V		C1511	1-123-875-11	ELECT 10MF 20% 50V	
C523	1-106-343-00	MYLAR 0.001MF 10% 100V		C1512	1-106-367-00	MYLAR 0.01MF 10% 100V	
C524	1-106-355-12	MYLAR 0.0033MF 10% 100V		C1513	1-102-963-00	CERAMIC 33PF 5% 50V	
C525	1-102-973-00	CERAMIC 100PF 5% 50V		C1520	1-102-108-00	CERAMIC 150PF 10% 50V	
C527	1-106-220-00	MYLAR 0.1MF 10% 100V		C1551	1-124-902-00	ELECT 0.47MF 20% 50V	
C531	1-126-104-11	ELECT 470MF 20% 25V		C1552	1-124-122-11	ELECT 100MF 20% 50V	
C532	1-124-122-11	ELECT 100MF 20% 50V		C1553	1-102-228-00	CERAMIC 470PF 10% 500V	
C533	1-106-216-00	MYLAR 0.068MF 10% 100V		C1630	1-124-463-00	ELECT 0.1MF 20% 50V	
C534	1-124-120-11	ELECT 220MF 20% 25V		C1631	1-126-530-11	ELECT 22MF 20% 50V	
C536	1-131-365-00	TANTALUM 10MF 10% 16V		C1651	1-106-220-00	MYLAR 0.1MF 10% 100V	
C537	1-124-499-11	ELECT 1MF 20% 50V		C1654	1-106-220-00	MYLAR 0.1MF 10% 100V	
C538	1-106-343-00	MYLAR 0.001MF 10% 100V		C1655	1-106-220-00	MYLAR 0.1MF 10% 100V	
C539	1-102-820-00	CERAMIC 330PF 5% 50V		C1656	1-124-902-00	ELECT 0.47MF 20% 50V	
C540	1-102-114-00	CERAMIC 470PF 10% 50V		C1657	1-106-383-00	MYLAR 0.047MF 10% 100V	
				C1707	1-130-481-00	MYLAR 0.0068MF 10% 50V	
				C1708	1-106-359-00	MYLAR 0.0047MF 10% 100V	
				C1710	1-106-395-00	MYLAR 0.15MF 10% 200V	
				C1711	1-124-925-11	ELECT 2.2MF 20% 50V	

D

The components identified by shading and mark Δ are critical for safety.
Replace only with part number specified.

REF.NO.	PART NO.	DESCRIPTION	REMARK	REF.NO.	PART NO.	DESCRIPTION	REMARK
C1712	1-124-927-11	ELECT 4.7MF 20% 50V		D809	8-719-911-19	DIODE 1SS119	
C1713	1-124-910-11	ELECT 47MF 20% 50V		D850	8-719-901-58	DIODE RGP15J	
C1714	1-124-911-11	ELECT 220MF 20% 50V		D1501	8-719-300-33	DIODE RU-3AM	
C1715	1-124-910-11	ELECT 47MF 20% 50V		D1502	8-719-911-19	DIODE 1SS119	
C1716	1-106-228-00	MYLAR 0.22MF 10% 100V		D1503	8-719-911-19	DIODE 1SS119	
C1717	1-124-120-11	ELECT 220MF 20% 25V		D1504	8-719-911-19	DIODE 1SS119	
C1718	1-136-165-00	FILM 0.1MF 5% 50V		D1505	8-719-016-42	DIODE MC932	
C1719	1-124-927-11	ELECT 4.7MF 20% 50V		D1515	8-719-911-19	DIODE 1SS119	
C1720	1-124-927-11	ELECT 4.7MF 20% 50V		D1550	8-719-911-19	DIODE 1SS119	
C1721	1-123-875-11	ELECT 10MF 20% 50V		D1552	8-719-300-33	DIODE RU-3AM	
C1722	1-124-927-11	ELECT 4.7MF 20% 50V		D1553	8-719-911-19	DIODE 1SS119	
C1723	1-123-875-11	ELECT 10MF 20% 50V		D1652	8-719-200-02	DIODE 10E2	
C1724	1-126-233-11	ELECT 22MF 20% 50V		D1701	8-719-901-58	DIODE RGP15J	
C1725	1-124-360-00	ELECT 1000MF 20% 16V		D1702	8-719-908-06	DIODE ERA81-005	
C1726	1-124-910-11	ELECT 47MF 20% 50V		D1703	8-719-908-06	DIODE ERA81-005	
C1727	1-124-910-11	ELECT 47MF 20% 50V		D1704	8-719-911-19	DIODE 1SS119	
C1734	1-124-360-00	ELECT 1000MF 20% 16V		D1705	8-719-911-19	DIODE 1SS119	
C1735	1-106-379-12	MYLAR 0.033MF 10% 100V		D1707	8-719-300-33	DIODE RU-3AM	
C1736	1-124-499-11	ELECT 1MF 20% 50V		D1708	8-719-109-81	DIODE RD4.7ES-B2	
C1740	1-102-244-00	CERAMIC 220PF 10% 500V		D1709	8-719-109-89	DIODE RD5.6ES-B2	
C5502	1-124-119-00	ELECT 330MF 20% 16V		D1710	8-719-109-89	DIODE RD5.6ES-B2	
C5505	1-124-463-00	ELECT 0.1MF 20% 50V					
<FILTER>				<IC>			
CF501	1-567-888-11	OSCILLATOR, CERAMIC		IC501	8-759-970-73	IC TEA2028B	
				IC502	8-759-944-57	IC TDA8170	
				IC503	8-749-920-60	IC STR90120	
				IC1501	8-759-942-16	IC TEA2031A	
				IC1701	8-759-103-93	IC UPC393C	
CND20	*1-508-767-00	PIN, CONNECTOR (5MM PITCH) 5P		IC1702	8-759-112-93	IC UPC4570HA-1	
CND21	*1-564-104-00	PIN, CONNECTOR 3P		IC1704	8-759-982-13	IC RC7812FA	
CND22	*1-564-515-11	PLUG, CONNECTOR 12P			*4-363-147-00	HEAT SINK, H.PIN; IC1704	
CND23	*1-564-506-11	PLUG, CONNECTOR 3P					
CND81	*1-564-506-11	PLUG, CONNECTOR 3P					
CND82	*1-508-765-00	PIN, CONNECTOR (5MM PITCH) 3P					
CND83	*1-564-038-00	CONNECTOR PLUG, DY (MINI) 6P					
CND84	*1-508-765-00	PIN, CONNECTOR (5MM PITCH) 3P					
CND85	*1-564-507-11	PLUG, CONNECTOR 4P					
CND87	*1-508-786-00	PIN, CONNECTOR (5MM PITCH) 2P					
CND801	*1-508-767-00	PIN, CONNECTOR (5MM PITCH) 5P					
<DIODE>							
D501	8-719-911-19	DIODE 1SS119		L501	1-408-225-00	INDUCTOR 3.3UH	
D502	8-719-200-02	DIODE 10E2		L801	1-459-111-00	COIL, DRAM CORE (CDI)	
D504	8-719-911-55	DIODE U05G		L803	1-459-104-00	COIL, DUST CORE	
D506	8-719-016-42	DIODE MC932		L804	1-408-235-00	INDUCTOR 2.2MMH	
D508	8-719-911-19	DIODE 1SS119		L806	1-459-111-00	COIL, DRAM CORE (CDI)	
D511	8-719-911-55	DIODE U05G		L807	1-408-938-00	INDUCTOR 22UH	
D512	8-719-911-55	DIODE U05G		L809	*1-420-872-00	COIL, AIR CORE	
D513	8-719-109-81	DIODE RD4.7ES-B2		L811	1-459-104-00	COIL, DUST CORE	
D520	8-719-109-89	DIODE RD5.6ES-B2		L812	1-408-698-00	INDUCTOR 8.2UH	
D591	8-719-911-19	DIODE 1SS119		L850	1-408-225-00	INDUCTOR 3.3UH	
D592	8-719-911-19	DIODE 1SS119		L1651	1-443-012-00	TRANSFORMER, DYNAMIC CONVERSION	
D593	8-719-911-19	DIODE 1SS119		L1652	1-459-583-11	COIL (WITH CORE)	
D801	8-719-300-33	DIODE RU-3AM		L1653	1-408-247-00	INDUCTOR 33MMH	
D802	8-719-300-33	DIODE RU-3AM		L1654	1-410-482-31	INDUCTOR 100UH	
D803	8-719-901-19	DIODE V11N		L1702	1-410-093-11	INDUCTOR 33MMH	
D804	8-719-911-55	DIODE U05G		L1703	1-459-592-11	COIL (WITH CORE) (PMC)	
D805	8-719-911-55	DIODE U05G		L1704	1-459-075-00	COIL, DYNAMIC CONVERSION CHUKE	
D806	8-719-945-80	DIODE ERC06-15S		L1705	1-408-235-00	INDUCTOR 2.2MMH	
D807	8-719-945-80	DIODE ERC06-15S					
D808	8-719-900-26	DIODE ERD29-08J					

D										V										D									
REF. NO. PART NO.		DESCRIPTION	REMARK	REF. NO. PART NO.		DESCRIPTION	REMARK	REF. NO. PART NO.		DESCRIPTION	REMARK	REF. NO. PART NO.		DESCRIPTION	REMARK	REF. NO. PART NO.		DESCRIPTION	REMARK										
<TRANSISTOR>																													
Q501	8-729-119-76	TRANSISTOR 2SA1175-HFE		R530	1-249-448-11	CARBON 1.2 5%	1/4W F	R825	1-216-341-11	METAL OXIDE 0.22 5%	1W F	R1733	1-249-414-11	CARBON 560 5%	1/4W														
Q502	8-729-119-76	TRANSISTOR 2SA1175-HFE		R531	1-247-881-00	CARBON 120K 5%	1/4W	R831	1-249-443-11	CARBON 0.47 5%	1/4W F																		
Q503	8-729-119-78	TRANSISTOR 2SC2785-HFE		R532	1-247-713-11	CARBON 1K 5%	1/4W	R832	1-247-692-11	CARBON 22 5%	1/4W F	R1734	1-249-393-11	CARBON 10- 5%	1/4W														
Q505	8-729-140-96	TRANSISTOR 2SD774-34		R533	1-249-393-11	CARBON 10 5%	1/4W	R833	1-216-379-11	METAL OXIDE 6.8 5%	2W F	R1735	1-249-428-11	CARBON 8.2K 5%	1/4W														
Q506	8-729-140-97	TRANSISTOR 2SB734-34		R534	1-246-543-00	CARBON 820K 5%	1/4W	R834	1-249-482-11	CARBON 4.7 5%	1/2W F	R1736	1-247-895-00	CARBON 470K 5%	1/4W														
Q507	8-729-119-76	TRANSISTOR 2SA1175-HFE		R536	1-247-725-11	CARBON 10K 5%	1/4W	R835	1-215-884-11	METAL OXIDE 47 5%	2W F	R1737	1-249-429-11	CARBON 10K 5%	1/4W														
Q509	8-729-900-80	TRANSISTOR DTC114ES		R537	1-249-463-11	CARBON 27K 5%	1/4W	R836	1-215-884-11	METAL OXIDE 47 5%	2W F	R1738	1-249-421-11	CARBON 2.2K 5%	1/4W														
Q510	8-729-900-80	TRANSISTOR DTC114ES		R538	1-249-441-11	CARBON 100K 5%	1/4W	R837	1-215-911-11	METAL OXIDE 100 5%	3W F																		
Q512	8-729-119-76	TRANSISTOR 2SA1175-HFE		R539	1-247-883-00	CARBON 150K 5%	1/4W	R839	1-249-429-11	CARBON 10K 5%	1/4W	R1739	1-249-429-11	CARBON 10K 5%	1/4W														
Q514	8-729-119-78	TRANSISTOR 2SC2785-HFE		R540	1-249-434-11	CARBON 27K 5%	1/4W	R840	1-249-496-11	CARBON 100K 5%	1/2W	R1740	1-249-435-11	CARBON 33K 5%	1/4W														
Q591	8-729-119-78	TRANSISTOR 2SC2785-HFE		R541	1-249-438-11	CARBON 56K 5%	1/4W	R841	1-247-713-11	CARBON 1K 5%	1/4W	R1741	1-249-429-11	CARBON 10K 5%	1/4W														
Q592	8-729-900-80	TRANSISTOR DTC114ES		R542	1-249-429-11	CARBON 10K 5%	1/4W	R842	1-247-713-11	CARBON 1K 5%	1/4W	R1742	1-249-432-11	CARBON 18K 5%	1/4W														
Q598	8-729-119-78	TRANSISTOR 2SC2785-HFE		R543	1-249-448-11	CARBON 1.2 5%	1/4W F	R843	1-216-389-11	METAL OXIDE 1 5%	3W F	R1743	1-247-895-00	CARBON 470K 5%	1/4W														
Q804	8-729-305-01	TRANSISTOR 2SD1941-07		R544	1-247-745-11	CARBON 330 5%	1/2W	R844	1-215-421-00	METAL 1K 1%	1/6W	R1744	1-249-429-11	CARBON 10K 5%	1/4W														
	*4-378-214-01	HOLDER, TR: Q804		R545	1-247-725-11	CARBON 10K 5%	1/4W	R845	1-214-913-00	METAL 100K 1%	1/2W	R1745	1-249-415-11	CARBON 680 5%	1/4W														
Q805	8-729-119-80	TRANSISTOR 2SC2688-LK		R546	1-249-434-11	CARBON 27K 5%	1/4W	R846	1-249-496-11	CARBON 100K 5%	1/2W	R1746	1-249-424-11	CARBON 3.9K 5%	1/4W														
Q806	8-729-122-12	TRANSISTOR 2SA1221		R547	1-249-423-11	CARBON 3.3K 5%	1/4W	R847	1-249-429-11	CARBON 10K 5%	1/4W	R1747	1-249-433-11	CARBON 22K 5%	1/4W														
Q807	8-729-107-53	TRANSISTOR 2SC2275A		R548	1-216-349-00	METAL OXIDE 1 5%	1W F	R848	1-215-925-11	METAL OXIDE 22K 5%	3W F	R1748	1-249-424-11	CARBON 3.9K 5%	1/4W														
Q1551	8-729-119-78	TRANSISTOR 2SC2785-HFE		R549	1-215-890-11	METAL OXIDE 470 5%	2W F	R849	1-215-925-11	METAL OXIDE 22K 5%	3W F	R1749	1-249-441-11	CARBON 100K 5%	1/4W														
Q1552	8-729-208-71	TRANSISTOR 2SC32988-0		R550	1-249-440-11	CARBON 82K 5%	1/4W	R1501	1-249-462-11	CARBON 22K 5%	1/4W	R1750	1-249-409-11	CARBON 220 5%	1/4W														
Q1608	8-729-119-78	TRANSISTOR 2SC2785-HFE		R551	1-246-545-00	CARBON 1M 5%	1/4W	R1502	1-249-434-11	CARBON 27K 5%	1/4W	R1751	1-249-429-11	CARBON 10K 5%	1/4W														
Q1609	8-729-119-78	TRANSISTOR 2SC2785-HFE		R553	1-215-869-11	METAL OXIDE 1K 5%	1W F	R1503	1-247-895-00	CARBON 470K 5%	1/4W	R1752	1-249-423-11	CARBON 3.3K 5%	1/4W														
Q1610	8-729-178-55	TRANSISTOR 2SC2785-E		R554	1-249-411-11	CARBON 330 5%	1/4W	R1504	1-249-435-11	CARBON 33K 5%	1/4W	R1754	1-249-429-11	CARBON 10K 5%	1/4W														
Q1613	8-729-119-76	TRANSISTOR 2SA1175-HFE		R555	1-249-749-00	CARBON 2.2M 5%	1/4W	R1505	1-249-433-11	CARBON 22K 5%	1/4W	R1755	1-249-429-11	CARBON 10K 5%	1/4W														
Q1653	8-729-195-82	TRANSISTOR 2SC2958		R556	1-249-405-11	CARBON 100 5%	1/4W	R1506	1-247-895-00	CARBON 470K 5%	1/4W	R1756	1-247-713-11	CARBON 1K 5%	1/4W														
Q1701	8-729-119-78	TRANSISTOR 2SC2785-HFE		R557	1-249-425-11	CARBON 4.7K 5%	1/4W	R1507	1-247-895-00	CARBON 470K 5%	1/4W	R1757	1-249-413-11	CARBON 470 5%	1/4W														
Q1703	8-729-208-71	TRANSISTOR 2SC32988-0		R558	1-247-903-00	CARBON 1M 5%	1/4W	R1508	1-249-438-11	CARBON 56K 5%	1/4W	R1758	1-249-423-11	CARBON 3.3K 5%	1/4W														
Q1704	8-729-140-96	TRANSISTOR 2SD774-34		R559	1-249-427-11	CARBON 6.8K 5%	1/4W	R1509	1-249-441-11	CARBON 100K 5%	1/4W	R1759	1-215-906-11	METAL OXIDE 15 5%	3W F														
Q1705	8-729-140-96	TRANSISTOR 2SD774-34		R560	1-249-411-11	CARBON 330 5%	1/4W	R1510	1-249-426-11	CARBON 5.6K 5%	1/4W	R1760	1-249-419-11	CARBON 1.5K 5%	1/4W														
Q1706	8-729-119-76	TRANSISTOR 2SA1175-HFE		R561	1-249-421-11	CARBON 2.2K 5%	1/4W	R1511	1-249-417-11	CARBON 1K 5%	1/4W	R1761	1-249-426-11	CARBON 5.6K 5%	1/4W														
Q1707	8-729-809-29	TRANSISTOR 2SC4159-E		R562	1-249-420-11	CARBON 1.8K 5%	1/4W	R1512	1-247-725-11	CARBON 10K 5%	1/4W	R1762	1-215-858-00	METAL OXIDE 15 5%	1W F														
Q1708	8-729-140-97	TRANSISTOR 2SB734-34		R563	1-249-417-11	CARBON 1K 5%	1/4W	R1513	1-247-883-00	CARBON 150K 5%	1/4W	R1763	1-249-421-11	CARBON 2.2K 5%	1/4W														
Q1709	8-729-119-78	TRANSISTOR 2SC2785-HFE		R565	1-249-423-11	CARBON 3.3K 5%	1/4W	R1514	1-249-417-11	CARBON 1K 5%	1/4W	R1764	1-249-409-11	CARBON 220- 5%	1/4W														
Q1710	8-729-119-78	TRANSISTOR 2SC2785-HFE		R566	1-249-435-11	CARBON 33K 5%	1/4W	R1516	1-249-432-11	CARBON 18K 5%	1/4W	R1774	1-249-421-11	CARBON 2.2K 5%	1/4W														
Q1711	8-729-119-78	TRANSISTOR 2SC2785-HFE		R567	1-249-422-11	CARBON 2.7K 5%	1/4W	R1517	1-249-411-11	CARBON 330 5%	1/4W	R1775	1-249-429-11	CARBON 10K 5%	1/4W														
Q1712	8-729-119-78	TRANSISTOR 2SC2785-HFE		R569	1-249-405-11	CARBON 100 5%	1/4W	R1518	1-249-429-11	CARBON 10K 5%	1/4W	R1776	1-247-706-11	CARBON 330 5%	1/4W														
Q1716	8-729-900-80	TRANSISTOR DTC114ES		R570	1-249-435-11	CARBON 33K 5%	1/4W	R1519	1-247-897-11	CARBON 560K 5%	1/4W	R1778	1-249-423-11	CARBON 3.3K 5%	1/4W														
Q1717	8-729-119-76	TRANSISTOR 2SA1175-HFE		R571	1-249-437-11	CARBON 47K 5%	1/4W	R1520	1-247-897-11	CARBON 560K 5%	1/4W	R1779	1-249-422-11	CARBON 2.7K 5%	1/4W														
<RESISTOR>																													
R500	1-247-897-11	CARBON 560K 5%	1/4W	R572	1-249-429-11	CARBON 10K 5%	1/4W	R1552	1-249-426-11	CARBON 5.6K 5%	1/4W	R1780	1-249-437-11	CARBON 47K 5%	1/4W														
R501	1-247-708-11	CARBON 470 5%	1/4W	R573	1-249-421-11	CARBON 2.2K 5%	1/4W	R1553	1-215-917-11	METAL OXIDE 1K 5%	3W F	R1781	1-249-427-11	CARBON 6.8K 5%	1/4W														
R502	1-249-409-11	CARBON 220 5%	1/4W	R575	1-249-435-11	CARBON 33K 5%	1/4W	R1554	1-249-407-11	CARBON 150 5%	1/4W	R1787	1-249-425-11	CARBON 4.7K 5%	1/4W														
R503	1-249-410-11	CARBON 270 5%	1/4W	R585	1-249-422-11	CARBON 2.7K 5%	1/4W	R1602	1-247-722-11	CARBON 5.6K 5%	1/4W	R1792	1-249-435-11	CARBON 33K 5%	1/4W														
R504	1-215-427-00	METAL 1.8K 1%	1/6W	R591	1-249-427-11	CARBON 6.8K 5%	1/4W	R1636	1-249-437-11	CARBON 47K 5%	1/4W	R1794	1-249-419-11	CARBON 1.5K 5%	1/4W														
R505	1-249-460-11	CARBON 15K 5%	1/4W	R592	1-249-429-11	CARBON 10K 5%	1/4W	R1637	1-249-437-11	CARBON 47K 5%	1/4W	R5113	1-249-467-11	CARBON 68K 5%	1/4W														
R506	1-249-428-11	CARBON 8.2K 5%	1/4W	R593	1-249-429-11	CARBON 10K 5%	1/4W	R1638	1-249-413-11	CARBON 470 5%	1/4W	R513A	1-249-461-11	CARBON 18K 5%	1/4W														
R509	1-249-424-11	CARBON 3.9K 5%	1/4W	R594	1-249-424-11	CARBON 3.9K 5%	1/4W	R1639	1-249-441-11	CARBON 100K 5%	1/4W	R5501	1-247-725-11	CARBON 10K 5%	1/4W														
R																													

D V

The components identified by shading and mark **A** are critical for safety.
Replace only with part number specified.

V	H2	H1	K
---	----	----	---

[illegible]

L K

REF. NO.	PART NO.	DESCRIPTION	REMARK	REF. NO.	PART NO.	DESCRIPTION	REMARK	REF. NO.	PART NO.	DESCRIPTION	REMARK	REF. NO.	PART NO.	DESCRIPTION	REMARK		
C223	1-130-481-00	MYLAR	0.0068MF	10%	50V			R011	1-247-708-11	CARBON	470 5%	1/4W	R080	1-249-417-11	CARBON	1K 5%	1/4W
C224	1-124-927-11	ELECT	4.7MF	20%	50V			R012	1-249-429-11	CARBON	10K 5%	1/4W	R081	1-249-429-11	CARBON	10K 5%	1/4W
C225	1-123-875-11	ELECT	10MF	20%	50V			R013	1-249-431-11	CARBON	15K 5%	1/4W	R082	1-249-417-11	CARBON	1K 5%	1/4W
C226	1-124-499-11	ELECT	1MF	20%	50V			R014	1-249-413-11	CARBON	470 5%	1/4W	R083	1-249-435-11	CARBON	33K 5%	1/4W
C227	1-123-875-11	ELECT	10MF	20%	50V			R015	1-249-413-11	CARBON	470 5%	1/4W	R084	1-249-433-11	CARBON	22K 5%	1/4W
C228	1-123-875-11	ELECT	10MF	20%	50V								R087	1-249-429-11	CARBON	10K 5%	1/4W
C229	1-124-463-00	ELECT	0.1MF	20%	50V			R016	1-249-413-11	CARBON	470 5%	1/4W					
C230	1-123-875-11	ELECT	10MF	20%	50V			R017	1-249-411-11	CARBON	330 5%	1/4W	R088	1-247-725-11	CARBON	10K 5%	1/4W
C231	1-136-169-00	MYLAR	0.22MF	10%	50V			R018	1-249-429-11	CARBON	10K 5%	1/4W	R089	1-249-429-11	CARBON	10K 5%	1/4W
C232	1-124-637-11	ELECT	1000MF	20%	50V			R020	1-247-725-11	CARBON	10K 5%	1/4W	R090	1-247-725-11	CARBON	10K 5%	1/4W
C233	1-124-927-11	ELECT	4.7MF	20%	50V			R021	1-249-417-11	CARBON	1K 5%	1/4W	R091	1-249-411-11	CARBON	330 5%	1/4W
C234	1-123-875-11	ELECT	10MF	20%	50V			R022	1-249-417-11	CARBON	1K 5%	1/4W	R092	1-247-725-11	CARBON	10K 5%	1/4W
C236	1-124-499-11	ELECT	1MF	20%	50V			R023	1-249-429-11	CARBON	10K 5%	1/4W					
C237	1-123-875-11	ELECT	10MF	20%	50V			R024	1-249-429-11	CARBON	10K 5%	1/4W	R093	1-247-718-11	CARBON	2.7K 5%	1/4W
C238	1-124-463-00	ELECT	0.1MF	20%	50V			R025	1-249-429-11	CARBON	10K 5%	1/4W	R094	1-249-461-11	CARBON	18K 5%	1/4W
C239	1-123-875-11	ELECT	10MF	20%	50V			R026	1-249-465-11	CARBON	47K 5%	1/4W	R095	1-247-724-11	CARBON	8.2K 5%	1/4W
C240	1-136-169-00	MYLAR	0.22MF	10%	50V								R096	1-249-460-11	CARBON	15K 5%	1/4W
C241	1-124-637-11	ELECT	1000MF	20%	50V			R027	1-249-465-11	CARBON	47K 5%	1/4W	R097	1-247-725-11	CARBON	10K 5%	1/4W
C242	1-124-637-11	ELECT	1000MF	20%	50V			R028	1-249-465-11	CARBON	47K 5%	1/4W					
C243	1-124-902-00	ELECT	0.47MF	20%	50V			R029	1-249-409-11	CARBON	220 5%	1/4W	R098	1-249-417-11	CARBON	1K 5%	1/4W
C244	1-124-902-00	ELECT	0.47MF	20%	50V			R032	1-249-429-11	CARBON	10K 5%	1/4W	R099	1-247-719-11	CARBON	3.3K 5%	1/4W
C245	1-124-478-11	ELECT	100MF	20%	25V			R033	1-249-429-11	CARBON	10K 5%	1/4W	R202	1-247-704-11	CARBON	220 5%	1/4W
C246	1-124-478-11	ELECT	100MF	20%	25V								R203	1-249-431-11	CARBON	15K 5%	1/4W
C247	1-102-074-00	CERAMIC	0.001MF	10%	50V			R034	1-249-429-11	CARBON	10K 5%	1/4W	R204	1-249-429-11	CARBON	10K 5%	1/4W
C248	1-102-074-00	CERAMIC	0.001MF	10%	50V			R035	1-249-431-11	CARBON	15K 5%	1/4W					
C249	1-130-497-00	MYLAR	0.15MF	5%	50V			R037	1-249-433-11	CARBON	22K 5%	1/4W	R205	1-249-433-11	CARBON	22K 5%	1/4W
C250	1-130-497-00	MYLAR	0.15MF	5%	50V			R038	1-249-459-11	CARBON	12K 5%	1/4W	R206	1-249-433-11	CARBON	22K 5%	1/4W
C251	1-102-030-00	CERAMIC	330PF	10%	500V			R039	1-249-459-11	CARBON	12K 5%	1/4W	R207	1-249-431-11	CARBON	15K 5%	1/4W
C252	1-102-030-00	CERAMIC	330PF	10%	500V								R208	1-249-433-11	CARBON	22K 5%	1/4W
C253	1-124-917-11	ELECT	33MF	20%	50V			R040	1-247-721-11	CARBON	4.7K 5%	1/4W	R209	1-249-433-11	CARBON	22K 5%	1/4W
C254	1-124-917-11	ELECT	33MF	20%	50V			R041	1-249-435-11	CARBON	33K 5%	1/4W					
C255	1-101-006-00	CERAMIC	0.047MF	50V				R042	1-249-461-11	CARBON	18K 5%	1/4W	R210	1-249-441-11	CARBON	100K 5%	1/4W
		<FILTER>						R043	1-249-417-11	CARBON	1K 5%	1/4W	R211	1-249-431-11	CARBON	15K 5%	1/4W
CF001	1-577-082-11	VIBRATOR, CERAMIC						R044	1-249-417-11	CARBON	1K 5%	1/4W	R212	1-249-423-11	CARBON	3.3K 5%	1/4W
		<CONNECTOR>						R045	1-249-417-11	CARBON	1K 5%	1/4W	R213	1-249-435-11	CARBON	33K 5%	1/4W
CNK1	*1-566-367-11	CONNECTOR, HINGE (RECEPTACLE)						R046	1-249-417-11	CARBON	1K 5%	1/4W	R214	1-247-704-11	CARBON	220 5%	1/4W
CNK2	*1-566-660-11	CONNECTOR, HINGE (PLUG) 18P						R047	1-249-417-11	CARBON	1K 5%	1/4W					
CNK3	*1-564-515-11	PLUG, CONNECTOR 12P						R048	1-247-725-11	CARBON	10K 5%	1/4W	R215	1-247-704-11	CARBON	220 5%	1/4W
CNK4	*1-564-510-11	PLUG, CONNECTOR 7P						R049	1-249-431-11	CARBON	15K 5%	1/4W	R216	1-247-704-11	CARBON	220 5%	1/4W
CNK5	*1-564-509-11	PLUG, CONNECTOR 6P											R217	1-247-704-11	CARBON	220 5%	1/4W
CNK6	*1-564-513-11	PLUG, CONNECTOR 10P						R050	1-249-425-11	CARBON	4.7K 5%	1/4W	R218	1-247-713-11	CARBON	1K 5%	1/4W
CNK7	*1-564-508-11	PLUG, CONNECTOR 5P						R051	1-249-425-11	CARBON	4.7K 5%	1/4W	R219	1-247-713-11	CARBON	1K 5%	1/4W
CNK8	*1-564-506-11	PLUG, CONNECTOR 3P						R052	1-247-708-11	CARBON	470 5%	1/4W					
CNK9	*1-566-367-11	CONNECTOR, HINGE (RECEPTACLE)						R053	1-249-441-11	CARBON	100K 5%	1/4W	R220	1-249-431-11	CARBON	15K 5%	1/4W
CNK10	*1-566-660-11	CONNECTOR, HINGE (PLUG) 18P						R054	1-249-435-11	CARBON	33K 5%	1/4W	R221	1-249-423-11	CARBON	3.3K 5%	1/4W
CNK11	*1-566-660-11	CONNECTOR, HINGE (PLUG) 18P						R055	1-249-423-11	CARBON	3.3K 5%	1/4W	R222	1-249-435-11	CARBON	33K 5%	1/4W
CNK12	*1-564-881-11	PLUG, CONNECTOR 4P						R056	1-249-417-11	CARBON	1K 5%	1/4W	R223	1-249-441-11	CARBON	100K 5%	1/4W
CNK13	*1-564-880-31	PLUG, CONNECTOR 3P						R057	1-247-725-11	CARBON	10K 5%	1/4W	R224	1-249-441-11	CARBON	100K 5%	1/4W
CNK21	*1-564-505-11	PLUG, CONNECTOR 2P						R058	1-247-725-11	CARBON	10K 5%	1/4W					
CNK22	*1-508-784-00	PIN, CONNECTOR (5MM PITCH) 1P						R059	1-247-725-11	CARBON	10K 5%	1/4W	R225	1-249-425-11	CARBON	4.7K 5%	1/4W
CNK23	*1-508-784-00	PIN, CONNECTOR (5MM PITCH) 1P											R226	1-249-409-11	CARBON	220 5%	1/4W
		<COMPOSITION CIRCUIT BLOCK>						R060	1-249-417-11	CARBON	1K 5%	1/4W	R231	1-249-469-11	CARBON	100K 5%	1/4W
CP001	1-233-153-11	COMPOSITION CIRCUIT BLOCK						R061	1-249-409-11	CARBON	220 5%	1/4W	R232	1-249-433-11	CARBON	22K 5%	1/4W
		<DIODE>						R062	1-249-429-11	CARBON	10K 5%	1/4W	R233	1-249-433-11	CARBON	22K 5%	1/4W
D001	8-719-109-71	DIODE RD3.9ES-B1						R063	1-249-429-11	CARBON	10K 5%	1/4W					
D002	8-719-911-19	DIODE ISS119						R064	1-249-429-11	CARBON	10K 5%	1/4W	R234	1-249-429-11	CARBON	10K 5%	1/4W
D003	8-719-911-19	DIODE ISS119											R235	1-247-891-00	FUSIBLE	1 5%	1/2W
D004	8-719-911-19	DIODE ISS119						R065	1-249-436-11	CARBON	39K 5%	1/4W	R236	1-249-441-11	CARBON	100K 5%	1/4W
		<RESISTOR>						R066	1-249-431-11	CARBON	15K 5%	1/4W	R239	1-249-441-11	CARBON	100K 5%	1/4W
								R067	1-249-409-11	CARBON	220 5%	1/4W					
								R068	1-249-423-11	CARBON	3.3K 5%	1/4W	R240	1-249-425-11	CARBON	4.7K 5%	1/4W
								R069	1-249-425-11	CARBON	4.7K 5%	1/4W	R241	1-249-409-11	CARBON	220 5%	1/4W
													R242	1-249-469-11	CARBON	100K 5%	1/4W
								R070	1-249-423-11	CARBON	3.3K 5%	1/4W	R247	1-249-433-11	CARBON	22K 5%	1/4W
								R071	1-249-429-11	CARBON	10K 5%	1/4W	R248	1-249-433-11	CARBON	22K 5%	1/4W
								R072	1-249-437-11	CARBON	47K 5%	1/4W					
								R073	1-249-411-11	CARBON	330 5%	1/4W	R249	1-249-429-11	CARBON	10K 5%	1/4W
								R074	1-215-900-11	METAL OXIDE	22K 5%	2W	R250	1-247-891-00	CARBON	330K 5%	1/4W
													R252	1-212-934-51	FUSIBLE	1 5%	1/2W
								R075	1-249-429-11	CARBON	10K 5%	1/4W					
								R077	1-247-725-11	CARBON	10K 5%	1/4W					
								R078	1-249-425-11	CARBON	4.7K 5%	1/4W	R255	1-249-419-11	CARBON	1.5K 5%	1/4W
								R079	1-249-417-11	CARBON	1K 5%	1/4W	R256	1-249-439-11	CARBON	68K 5%	1/4W

K J

REF. NO.	PART NO.	DESCRIPTION	REMARK
R257	1-247-715-11	CARBON 1.5K 5% 1/4W	
R258	1-249-439-11	CARBON 68K 5% 1/4W	
R259	1-249-469-11	CARBON 100K 5% 1/4W	
R260	1-249-469-11	CARBON 100K 5% 1/4W	
R261	1-249-437-11	CARBON 47K 5% 1/4W	
R262	1-249-437-11	CARBON 47K 5% 1/4W	
R263	1-249-441-11	CARBON 100K 5% 1/4W	
R264	1-249-441-11	CARBON 100K 5% 1/4W	
R265	1-249-423-11	CARBON 3.3K 5% 1/4W	
R266	1-249-423-11	CARBON 3.3K 5% 1/4W	
R270	1-249-418-11	CARBON 1.2K 5% 1/4W	
R271	1-249-418-11	CARBON 1.2K 5% 1/4W	

*A-1388-117-A J BOARD, COMPLETE			

<CAPACITOR>			
C1401	1-124-910-11	ELECT 47MF 20% 50V	
C1402	1-126-103-11	ELECT 470MF 20% 16V	
C1403	1-124-910-11	ELECT 47MF 20% 50V	
C1404	1-124-910-11	ELECT 47MF 20% 50V	
C1405	1-124-910-11	ELECT 47MF 20% 50V	
C1407	1-124-910-11	ELECT 47MF 20% 50V	
C1408	1-124-902-00	ELECT 0.47MF 20% 50V	
C1409	1-102-824-00	CERAMIC 470PF 5% 50V	
C1410	1-124-902-00	ELECT 0.47MF 20% 50V	
C1411	1-102-824-00	CERAMIC 470PF 5% 50V	
C1412	1-124-902-00	ELECT 0.47MF 20% 50V	
C1413	1-124-902-00	ELECT 0.47MF 20% 50V	
C1414	1-124-910-11	ELECT 47MF 20% 50V	
C1415	1-101-003-00	CERAMIC 0.0047MF 50V	
C1416	1-101-003-00	CERAMIC 0.0047MF 50V	
C1417	1-124-910-11	ELECT 47MF 20% 50V	
C1418	1-124-902-00	ELECT 0.47MF 20% 50V	
C1419	1-126-101-11	ELECT 100MF 20% 16V	
C1420	1-124-902-00	ELECT 0.47MF 20% 50V	
C1421	1-124-902-00	ELECT 0.47MF 20% 50V	
C1422	1-124-902-00	ELECT 0.47MF 20% 50V	
C1425	1-101-003-00	CERAMIC 0.0047MF 50V	
C1426	1-102-824-00	CERAMIC 470PF 5% 50V	
C1427	1-102-824-00	CERAMIC 470PF 5% 50V	
C1428	1-101-003-00	CERAMIC 0.0047MF 50V	
C1431	1-124-910-11	ELECT 47MF 20% 50V	
C1432	1-101-006-00	CERAMIC 0.047MF 50V	
C1433	1-101-006-00	CERAMIC 0.047MF 50V	
C1434	1-101-006-00	CERAMIC 0.047MF 50V	
C1435	1-101-006-00	CERAMIC 0.047MF 50V	
C1436	1-101-006-00	CERAMIC 0.047MF 50V	
C1437	1-101-006-00	CERAMIC 0.047MF 50V	
C1438	1-101-006-00	CERAMIC 0.047MF 50V	
C1439	1-101-006-00	CERAMIC 0.047MF 50V	
C1440	1-101-006-00	CERAMIC 0.047MF 50V	
C1441	1-101-006-00	CERAMIC 0.047MF 50V	
<CONNECTOR>			
CN1401	1-536-996-11	TERMINAL BOARD, INPUT/OUTPUT	
CN1402	1-535-741-11	TERMINAL, S	
CN1403	1-565-838-11	PIN JACK BLOCK 2P	
CNJ1	1-568-016-11	SOCKET 21P	
CNJ2	1-568-016-11	SOCKET 21P	

REF. NO.	PART NO.	DESCRIPTION	REMARK
CNJ3	*1-566-641-11	CONNECTOR, HINGE (TAB) 18P	
CNJ4	*1-566-641-11	CONNECTOR, HINGE (TAB) 18P	
CNJ5	*1-566-693-11	PIN, CONNECTOR 2P	
<DIODE>			
D1401	8-719-110-14	DIODE RD9.1ES-B3	
D1402	8-719-110-14	DIODE RD9.1ES-B3	
D1403	8-719-110-14	DIODE RD9.1ES-B3	
D1404	8-719-110-14	DIODE RD9.1ES-B3	
D1405	8-719-110-14	DIODE RD9.1ES-B3	
D1406	8-719-110-14	DIODE RD9.1ES-B3	
D1407	8-719-110-14	DIODE RD9.1ES-B3	
D1408	8-719-110-14	DIODE RD9.1ES-B3	
D1409	8-719-110-14	DIODE RD9.1ES-B3	
D1410	8-719-110-14	DIODE RD9.1ES-B3	
D1411	8-719-110-14	DIODE RD9.1ES-B3	
D1412	8-719-110-14	DIODE RD9.1ES-B3	
D1413	8-719-110-14	DIODE RD9.1ES-B3	
D1414	8-719-110-14	DIODE RD9.1ES-B3	
<IC>			
IC1401	8-752-032-27	IC CXA1114P	
IC1402	8-759-946-32	IC TEA2014A	
<COIL>			
L1401	1-459-407-00	COIL, FERRITE CHOKE	
L1402	1-459-407-00	COIL, FERRITE CHOKE	
L1403	1-459-407-00	COIL, FERRITE CHOKE	
L1404	1-459-407-00	COIL, FERRITE CHOKE	
<TRANSISTOR>			
Q1401	8-729-119-76	TRANSISTOR 2SA1175-HFE	
Q1402	8-729-119-76	TRANSISTOR 2SA1175-HFE	
Q1403	8-729-119-76	TRANSISTOR 2SA1175-HFE	
<RESISTOR>			
R1401	1-249-409-11	CARBON 220 5% 1/4W	
R1402	1-249-409-11	CARBON 220 5% 1/4W	
R1403	1-249-437-11	CARBON 47K 5% 1/4W	
R1404	1-249-403-11	CARBON 68 5% 1/4W	
R1405	1-249-413-11	CARBON 470 5% 1/4W	
R1406	1-249-422-11	CARBON 2.7K 5% 1/4W	
R1407	1-249-417-11	CARBON 1K 5% 1/4W	
R1408	1-247-804-11	CARBON 75 5% 1/4W	
R1409	1-249-409-11	CARBON 220 5% 1/4W	
R1410	1-249-409-11	CARBON 220 5% 1/4W	
R1411	1-249-413-11	CARBON 470 5% 1/4W	
R1412	1-249-417-11	CARBON 1K 5% 1/4W	
R1413	1-247-688-11	CARBON 10 5% 1/4W	
R1414	1-249-409-11	CARBON 220 5% 1/4W	
R1415	1-249-404-00	CARBON 82 5% 1/4W	
R1416	1-249-417-11	CARBON 1K 5% 1/4W	
R1417	1-247-713-11	CARBON 1K 5% 1/4W	
R1418	1-249-427-11	CARBON 6.8K 5% 1/4W	
R1419	1-249-429-11	CARBON 10K 5% 1/4W	
R1420	1-249-417-11	CARBON 1K 5% 1/4W	
R1421	1-249-434-11	CARBON 27K 5% 1/4W	
R1422	1-249-434-11	CARBON 27K 5% 1/4W	
R1423	1-249-434-11	CARBON 27K 5% 1/4W	
R1424	1-249-434-11	CARBON 27K 5% 1/4W	

J

The components identified by shading and mark **A** are critical for safety. Replace only with part number specified.

REF. NO.	PART NO.	DESCRIPTION	REMARK		
R1425	1-249-434-11	CARBON	27K	5%	1/4W
R1426	1-249-434-11	CARBON	27K	5%	1/4W
R1427	1-249-409-11	CARBON	220	5%	1/4W
R1428	1-249-409-11	CARBON	220	5%	1/4W
R1429	1-249-409-11	CARBON	220	5%	1/4W
R1430	1-249-440-11	CARBON	82K	5%	1/4W
R1431	1-247-738-11	CARBON	82	5%	1/2W
R1432	1-249-427-11	CARBON	6.8K	5%	1/4W
R1433	1-247-725-11	CARBON	10K	5%	1/4W
R1434	1-247-804-11	CARBON	75	5%	1/4W
R1435	1-247-895-00	CARBON	470K	5%	1/4W
R1436	1-247-895-00	CARBON	470K	5%	1/4W
R1437	1-247-804-11	CARBON	75	5%	1/4W
R1438	1-249-404-00	CARBON	82	5%	1/4W
R1439	1-249-404-00	CARBON	82	5%	1/4W
R1440	1-249-404-00	CARBON	82	5%	1/4W
R1441	1-247-895-00	CARBON	470K	5%	1/4W
R1442	1-247-895-00	CARBON	470K	5%	1/4W
R1443	1-249-437-11	CARBON	47K	5%	1/4W
R1444	1-249-413-11	CARBON	470	5%	1/4W
R1445	1-249-437-11	CARBON	47K	5%	1/4W
R1446	1-249-437-11	CARBON	47K	5%	1/4W
R1447	1-249-437-11	CARBON	47K	5%	1/4W
R1448	1-247-704-11	CARBON	220	5%	1/4W
R1449	1-247-804-11	CARBON	75	5%	1/4W
R1450	1-249-415-11	CARBON	680	5%	1/4W
R1451	1-249-415-11	CARBON	680	5%	1/4W
R1452	1-249-408-11	CARBON	180	5%	1/4W
R1453	1-249-408-11	CARBON	180	5%	1/4W
R1454	1-247-708-11	CARBON	470	5%	1/4W
R1455	1-247-708-11	CARBON	470	5%	1/4W

MISCELLANEOUS					

A	1-426-433-11	COIL, DEMAGNETIZATION			
A	1-451-315-11	DEFLECTION YOKE (Y34FPA)			
A	1-452-032-00	MAGNET, DISK; 10MM ϕ			
A	1-452-094-00	MAGNET, ROTATABLE DISK; 15MM ϕ			
A	1-452-468-11	NECK ASSY, PICTURE TUBE (NA321)			
A	1-574-745-11	CORD, POWER (WITH CONNECTOR)			
S901	A 1-571-877-11	SWITCH, PUSH (AC POWER)			
V901	A 8-733-721-05	PICTURE TUBE (A80JV10X)			

ACCESSORIES AND PACKING MATERIALS					

PART NO.	DESCRIPTION	REMARK			
A-1470-881-A	COMMANDER ASSY (RM-684)				
*X-4391-921-1	PLATE ASSY, BOTTOM				
3-750-002-91	MANUAL, INSTRUCTION				
*4-388-135-01	BAG, PROTECTION				
*4-391-970-01	BAND				
*4-392-445-01	CUSHION (UPPER) (ASSY)				
*4-392-446-01	CUSHION (LOWER) (ASSY)				
*4-392-932-01	CUSHION (FRONT)				
*4-393-236-01	INDIVIDUAL CARTON				